


D20MX

Processor



Hardware User's Manual

994-0140

Version 1.20 Revision 0

Copyright Notice

© 2012 - 2013, General Electric Company. All rights reserved.

The information contained in this online publication is the exclusive property of General Electric Company, except as otherwise indicated. You may view, copy and print documents and graphics incorporated in this online publication (the "Documents") subject to the following: (1) the Documents may be used solely for personal, informational, non-commercial purposes; (2) the Documents may not be modified or altered in any way; and (3) General Electric Company withholds permission for making the Documents or any portion thereof accessible via the internet. Except as expressly provided herein, you may not use, copy, print, display, reproduce, publish, license, post, transmit or distribute the Documents in whole or in part without the prior written permission of General Electric Company.

The information contained in this online publication is proprietary and subject to change without notice. The software described in this online publication is supplied under license and may be used or copied only in accordance with the terms of such license.

Trademark Notices

GE and  are trademarks and service marks of General Electric Company.

* Trademarks of General Electric Company.

ERNI is a registered trademark of ERNI Elektroapparate GMBH. Hyperterminal is a registered trademark of Hilgraeve, Tera Term is a registered trademark of T. Teranishi, Incorporated. IEC is a registered trademark of Commission Electrotechnique Internationale. IEEE is a registered trademark of the Institute of Electrical and Electronics Engineers, Inc. Internet Explorer, Microsoft, and Windows are registered trademarks of Microsoft Corporation. JAVA and J2SE are registered trademarks of Sun Microsystems, Inc. Maxell is a registered trademark of Hitachi Maxell, Ltd. MiniSQL is a trademark of Hughes Technologies. Modbus is a registered trademark of Schneider Automation Inc. Panduit is a registered trademark of Panduit Corp. Saft is a registered trademark of SAFT société anonyme. SEL is a registered trademark of Schweitzer Engineering Laboratories, Inc. Silicon Systems is a registered trademark of Silicon Systems, Inc. Sonnenschein is a registered trademark of Deutsche Exide GMBH. Tadiran is a registered trademark of Tadiran Israel Electronics Industries Ltd. Toshiba is a registered trademark of Kabushiki Kaisha Toshiba, doing business as Toshiba Corporation. VESA is registered trademark of Video Electronics Standards Association Corporation.

Other company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies.



This printed manual is recyclable.
Please return for recycling where facilities exist.

D20MX Processor

Table of contents

ABOUT THIS DOCUMENT	Purpose 7
	Intended audience 7
	Additional documentation 7
	How to use this manual 8
	Document conventions 8
	Safety words and definitions..... 9

PRODUCT SUPPORT	Search technical support 11
	Contact customer support 11
	Product returns..... 12
	Upgrade your D20MX processor firmware 12

BEFORE YOU START	Safety precautions 13
	Warning symbols
	Regulatory compliance information
	CE Mark compliance
	Product overview.....
	Product design.....
	D20MX Processor
	Security
	D20MX applications
	Firmware/FPGA versions
	D20 chassis
	Power supply
	Modems
	Peripherals.....
	Ordering guide.....
	D20MX upgrade kits.....
	Product specifications
	Storage recommendations.....
	Storage conditions

INSTALLING THE D20MX	D20 chassis layouts31
	Installation steps33
	Retrofitting the D20MX in an existing D2035
	Required tools and materials37
	Grounding the D20MX38
	Unpacking the D20MX38
	Package contents38
	Connecting the power supply38
CONNECTING TO DEVICES AND NETWORKS	Cabling overview41
	D20MX front panel connectors41
	General cabling requirements42
	Serial43
	D.20 Link43
	Twisted-pair Ethernet (for 526-3001 only)44
	Fiber optic Ethernet (for 526-3003 and 526-3005LF only)45
	LAN redundancy46
	IP addresses46
	RS-23249
	D20 system redundancy49
	Failover sequence51
	Required components51
	RS-232 switch panel operation52
	Redundancy wiring diagrams52
POWERING-UP AND TESTING	Required for testing55
	Accessing WESMAINT II+ using a terminal56
	Terminal Emulation56
	SHELL56
	Power up and test steps56
	Set up a PC to act as a WESMAINTII+ terminal57
	Power up the D20MX57
	Automatic on-line start-up test57
	Code and configuration files58
	Further testing58
	Test for redundancy58
	Check that fail-over is functioning correctly59
	Check that switch-over is functioning correctly59
	Verify either hardware or software switch-over60
CONFIGURING THE SOFTWARE	Introduction to the D20MX software61
	D20MX user accounts62
	Remote and local user accounts62
	Factory default user account62
	System default user account62
	Download image files to the D20MX63
	When to download63
	Prerequisites for image download63
	Download software over a serial connection64

	Download image files over a network connection.....	66
	Firmware integrity.....	68
	Committing new firmware.....	68
	Reverting old firmware.....	69
	Migrate D20MX application definitions to SGConfig.....	69
	Transfer D20/D200 configurations to the D20MX	70
	Transferring a D20 configuration to the D20MX	70
	Transferring a D200 configuration to the D20MX.....	77
	Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro.....	78
	Updating a D20 configuration to use the D20MX firmware definition with ConfigPro ..	78
	Updating a D200 configuration to use the D20MX firmware definition with ConfigPro ..	81
	Software (feature) licensing	82
<hr/>		
USING THE D20MX	Front panel LEDs	85
	Operational status LEDs.....	85
	LAN port status LEDs	86
	Fiber optic port status LEDs	86
<hr/>		
SERVICING THE D20MX	Performing periodic inspection	87
	Removing the D20MX processor module	87
<hr/>		
DEFAULT ROLE-BASED ACCESS CONTROL MODEL	Configured roles in the D20MX	89
<hr/>		
STANDARDS & PROTECTION	Compliance standards	97
<hr/>		
FREQUENTLY ASKED QUESTIONS	Questions and answers.....	101
<hr/>		
USING CONFIGPRO WITH D20MX	Transferring D20 configurations to the D20MX.....	104
	Configuration file in project directory	118
	Downloading a D20MX configuration.....	119
	Local [serial] transfer of configuration.....	119
	Remote [secure] transfer of configuration.....	125
	Application definition files and default configurations.....	128
	Staging factory default configuration files.....	128
	Installing application definitions: archived.....	129
	Installing application definitions: non-archived.....	132
<hr/>		
LIST OF ACRONYMS	Acronym Definitions	137

D20MX Processor

About this Document

Purpose

This manual provides information about installing, setting up, using and maintaining your D20MX™ Processor. This manual does not provide any procedures for configuring the software of the D20MX.

Intended audience

This manual is intended for use by field technicians and maintenance personnel who are responsible for the installation, wiring and maintenance of SCADA equipment. This manual assumes that the user is experienced in:

- Electrical utility applications
- Electrical wiring and safety procedures
- Related other manufacturers' products, such as protective relays and communications equipment

Additional documentation

For the most current version of the D20MX Hardware User's Manual, please download a copy from: <http://www.gedigitalenergy.com/app/ViewFiles.aspx?prod=d20mx&type=3>

For further information about the D20MX, refer to the following documents.

- *SGConfig™ Online Help*
- D20/D200 Installation and Operation Guide, 994-0078
- Application Configuration Guides and User Guides (available on the D20MX Documentation CD)

How to use this manual

This manual describes how to install the D20MX and get it up and running for the first time. Procedures are provided for all component options available for the D20MX. The components included in your D20MX depend on what was ordered for your substation application.

The software-related procedures in this manual are based on using a computer running Windows® XP. Some steps and dialog boxes may vary slightly if you are using another version of Windows.

Document conventions

The following typographic conventions are used throughout this manual:

Bold face is used for:

- Names of software program menus, editors, and dialog boxes; also for the names of menu commands, keyboard keys, icons and desktop shortcuts, and buttons and fields in editors and dialog boxes
- Names of hardware components
- User input that must be typed exactly

Italic face is used for:

- Emphasis
- Cross-references to sections, figures and tables within this manual and for titles of other documents
- File and directory names; examples of directory paths are generally given in the Windows format
- Placeholders for user input that is specific to the user. May also include angle brackets around the placeholder if the placeholder is already in italic text. For example, c:\<product>\product.def
- References to a parameter or field value shown

Safety words and definitions

Before attempting to install or use the device, review all safety indicators in this document to help prevent injury, equipment damage or downtime.

The following safety and equipment symbols are used in this document:



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



Indicates practices that are not related to personal injury.

D20MX Processor

Product Support

If you need help with any aspect of your GE Digital Energy product, you have a few options.

Search technical support

The GE Digital Energy Web site provides fast access to technical information, such as manuals, release notes and knowledge base topics at:

<http://www.gedigitalenergy.com>

Contact customer support

The GE Digital Energy Customer Service Center is open 24 hours a day, seven days a week for you to talk directly to a GE representative.

In the U.S. and Canada, call toll-free: 1 800-547-8629

International customers, please call: + 1 905-927-7070

Or e-mail to multilin.tech@ge.com

Have the following information ready to give to Customer Service:

- Ship to address (the address that the product is to be returned to)
- Bill to address (the address that the invoice is to be sent to)
- Contact name
- Contact phone number
- Contact fax number
- Contact e-mail address
- Product number / serial number
- Description of problem

The Customer Service centre will provide you with a case number for your reference.

Product returns

A Return Merchandise Authorization (RMA) number must accompany all equipment being returned for repair, servicing, or for any other reason. Before you return a product, please contact GE Digital Energy to obtain an RMA number and instructions for return shipments. You will be sent the RMA number and RMA documents via fax or e-mail. Once you receive the RMA documents, attach them to the outside of the shipping package and ship to GE.



NOTE

Product returns will not be accepted unless accompanied by the Return Merchandise Authorization number.

Upgrade your D20MX processor firmware

The firmware of your D20MX Processor can be upgraded to provide the latest functionality and improvements. Visit the customer support web site at <http://www.gedigitalenergy.com> to download the upgrade software and instruction guide.

D20MX Processor

Chapter 1: Before You Start

The D20MX Substation Gateway is a specialized computing platform which executes communications and energy management applications for monitoring and control of electrical substations. The D20MX is capable of consolidating data from multiple slave devices connected through communication channels (DCA: Data Collection Applications) and D20 Input / Output Modules in a single database. The D20MX can execute local logic, aggregate data, process data through one of multiple applications (DTA: Data Translation Applications) and report data upstream to master stations through different server protocols (DPA: Data Processing Applications).

The new D20MX processor card is a pin-for-pin compatible replacement for all generations of the D20 SBC, providing the latest revisions of common D20 applications and performance enhancements to support NERC-compliant Cyber security.

Before you begin installing and using the D20MX, review the information in this chapter, including the following topics:

- Safety precautions
- Regulatory compliance information
- Product overview
- Product specifications
- Storage recommendations

Read and thoroughly understand this manual before installing and operating the unit. Save these instructions for later use and reference.



WARNING! Failure to observe the instructions in this manual may result in serious injury or death.

Safety precautions

Follow all safety precautions and instructions in this manual.

Only qualified personnel should work on the D20MX. Maintenance personnel should be familiar with the technology and the hazards associated with electrical equipment.








- Never work alone.

- Before performing visual inspections, tests, or maintenance on this equipment, isolate or disconnect all hazardous live circuits and sources of electric power. Assume that all circuits are live until they have been completely de-energized, tested, and tagged. Pay particular attention to the design of the power system. Consider all sources of power, including the possibility of back feed.
- Turn off all power supplying the equipment in which the D20MX is to be installed before installing and wiring the D20MX.
- Operate only from the power source specified on the installed power supply module.
- Beware of potential hazards and wear personal protective equipment.
- The successful operation of this equipment depends upon proper handling, installation, and operation. Neglecting fundamental installation requirements may lead to personal injury as well as damage to electrical equipment or other property.
- All AC voltage terminals are protected from accidental contact by a mechanical safety shield.
- All electronic components within the D20MX are susceptible to damage from electrostatic discharge. To prevent damage when handling this product use approved static control procedures.
- Hazardous voltages can cause shock, burns or death. To prevent exposure to hazardous voltages, disconnect and lock out all power sources before servicing and removing components.
- If the D20MX is used in a manner not specified in this manual, the protection provided by the equipment may be impaired.
- Changes or modifications made to the unit not authorized by GE Digital Energy could void the warranty.

Warning symbols

Table 1 explains the meaning of warning symbols that may appear on the D20MX.

Table 1: Warning symbols

Symbol	Description
	The relevant circuit is direct current.
	The relevant circuit is alternating current.
	Caution: Refer to the documentation for important operation and maintenance instructions. Failure to take or avoid specified actions could result in loss of data or physical damage.
	Warning: Dangerous voltage constituting risk of electric shock is present within the unit. Failure to take or avoid specified actions could result in physical harm to the user.
	Earth/Ground Terminal
	Protective Ground Terminal
	Caution: Hot Surface

Regulatory compliance information

CE Mark compliance

The D20MX is rated as CISPR 11 Group 1 Class “A” equipment.

To meet essential safety requirements of the LV Directive 2006/95/EC, the D20 chassis must be installed in a secondary cabinet if an operating voltage on any of the terminals is equal to or higher than 50 VAC or 75 VDC. Proper wiring practices and applicable local safety standards defining protection against electrical shock must be followed at all times.



To provide higher EMC immunity and maintain CE Mark compliance, the serial cables used for permanent RS-232 and RS-485 connections must comply with the following requirements:

- Cables must be shielded
- D type connector covers must provide EMC shielding (e.g., metallized plastic or die cast metal covers) for permanently connected RS-232 cables

NOTICE

Class “A” equipment is intended for use in an industrial environment. The equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause interference to other devices in the vicinity. If this equipment does cause interference with other devices, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving device
- Increase the separation between the equipment
- Connect the equipment into an outlet on a circuit different from that to which the other device(s) is connected
- Consult the manufacturer or field service technician for help

Product overview

The D20 is a standalone remote terminal unit (RTU). It consists of a D20MX processor board, power supply, optional termination panels, and optional communications equipment in a 3U tall, 19-inch wide chassis. These components, combined with software applications running on the D20MX, form the D20 RTU System.

The D20 acts as a data concentrator and central processor. Field data gathered through the peripheral modules and external Intelligent Electronic Devices (IEDs) are stored in the system database and can be accessed by the application programs loaded on the D20.

Product design

The D20 design has horizontally mounted processor boards, with multiple boards in some versions.

Peripheral I/O boards operate independently of the main chassis and D20MX processor board. This means that you can use a D20 without direct connection to peripheral boards so that it acts as a master data concentrator to other RTUs. You can also hot-swap the peripherals without powering down the main processor. For information on peripheral modules, see the *D20/D200 Installation and Operations Guide* (part number 994-0078); see section: *Connections and Configuration*.

D20MX Processor

The D20MX is a single board computer built around a 667 MHz embedded PowerQUICC II Pro processor. The D20MX permits the D20 to be NERC CIPS compliant and introduces compliance to IEC standards; refer to *Appendix A, Standards & Protection* for the complete listing.

The D20MX can be retrofitted into either a D20 3U single-node VME chassis or D20 3U non-VME chassis. In a single-node VME chassis, this one processor module replaces the previous D20 M, M++, ME, and MEII CPU cards.

Due to aging printed circuit board assembly and mechanical constraints, only certain chassis from 2002 and onward can be used with a D20MX. This comprises the following chassis:

- D20 VME chassis 500-0280 Release 08 or higher,
- D20 Non-VME chassis 500-0305 Release 18 or higher

A solid partition between the Main processor bay and accessory bay prevents access to the harness from the fiber card to D20MX card (only applicable to the 526-3005LF fiber card version).

Security

The D20MX provides the following new security improvements over its predecessors:

- Centralized user authentication and authorization (RADIUS), including integration with Microsoft Servers using NPS
- Role Based Access Control (RBAC) keeping operator and engineering activities separated, logged and simple
- NERC compliant passwords, with strong complexity rules and one-way encrypted
- Full auditing including Syslog integration to enterprise systems
- SFTP for secure network-based firmware upgrades and configuration file transfers
- SSH for secure network access to WESMAINT II+.

To take advantage of these improvements, refer to the WESMAINT II+ for the D20MX Configuration Guide (B014-1NCG) for details of these security features of the D20MX.

D20MX applications

Table 2 lists the applications included in the D20MX firmware.

The applications that changed or were added from the previous release is indicated in the **Changed** column where:

- New indicates that the application definition is new to this release.
- Yes indicates that the application definition is updated for this release.

For more information about the changes, contact customer support.

The **Application Definition Version** column indicates the application definitions in the SAN0001 file.

Table 2: D20MX application definitions

License Group	D20MX Application ID	Application Name	Description	Application Definition Version	Changed
Common Application Definitions					
001	A009	PG&E DPA	Pacific Gas and Electric (PG&E) data-processing application (DPA) for remote terminal units (RTUs).	805	New
	A026-1	Communication Watchdog DTA	Reports on the state of communications between the RTU and a remote device (Data Translation Application).	321	

License Group	D20MX Application ID	Application Name	Description	Application Definition Version	Changed
	A027	SOE Logger DTA	The Sequence-of-Events Logger DTA processes sequence of events (SOEs) from any sub-set of the system digital input and/or analog input points.	832	
	A030	Accumulator Freeze DTA	Detects system status point changes and system accumulator point freezes.	300	
001	A033-5	TEJAS V DPA	Emulates a remote terminal unit utilizing the (Valmet/Metso/Telvent) TEJAS V communication protocol.	211	
	A035	Analog Reference DTA	Monitors analog input points and provides the system database with pseudo analog values that represent either correctly functioning analog input hardware (good reference value), or failed analog input hardware (bad reference value).	211	
001	A036N	ProLogic Executor DTA for D20MX	Provides user programmable soft logic automation functionality.	421	
	A059	Modbus DCA	Acts as a data concentrator for one or more Sub-Remote Units (SRUs) using the MODBUS communication protocol (RTU & ASCII modes).	911	
	A068	Modbus DPA	Capable of communicating with one or more master stations using the MODBUS protocol (RTU & ASCII modes).	311	
	A078	SEL Gateway DCA	A sub-master within a SCADA system, controlling SEL relay equipment using SEL's ASCII character-based relay protocol.	610	New
	A083-0	Calculator DTA	Convenient and flexible soft logic utility that can perform applications such as substation level interlocking, feeder interlocking, and converting digital inputs to control outputs for driving a map board.	342	
	A088-0	Substation Maintenance DTA	Allows status and analog input values to be suppressed for maintenance purposes.	203	
	A101-0	IEC 870-5-101 DPA	Communicate with one or more hosts using the IEC 60870-5-101/104 (T101) protocol. Has the ability to function as several distinct IEC 60870-5-101/104 RTUs. Supports the unbalanced version of the data link.	906	New
001	A113N	PSR DCA for D20MX	Programmable Synchrocheck Relay (PSR) DCA acts as a data concentrator for several remote PSRs. The DCA and remote PSRs function as a remote synchronous closure controller.	400	Yes
	A118	Failover DTA	Allows configurable combination of control requests to result in a failover or switchover of a redundant system.	103	
	A123-0	NGC General DTA	Generates control lockout indications, digital input suppression or unsuppression indications, and control active indications.	111	
	A184-0	General Alarm DTA	Takes several alarms and groups them together under one General Alarm.	120	
001	A185-0	W18979 DPA	Emulates the Landis & Gyr 8979 RTU. Communicates with multiple master stations, over redundant communication lines.	303	New
001	A199-0	HR6000/XA-21 (DPA)	Communicates with one or more hosts using the Harris HR6000/XA-21 protocol, emulating several HR6000/XA-21 LRUs. Supports multiple communication ports, multiple LRUs per communication port, and redundant porting.	106	New
	B003	D.20 Peripheral Link DCA	The D.20 Peripheral Link is responsible for surveillance and control of digital and analog values in the D.20 I/O peripherals.	751	
	B008-1	System Point Database	Maintains the database of system points in the RTU.	311	Yes
	B012N	IRIG-B DCA for D20MX	Provides Universal Time Coordination (UTC) using the IRIG-B pulse frame, as specified by IRIG Standard 200-04 September 2004 Edition.	201	
	B013	DNP V3.00 Data Link	Provides services for software applications to send and receive messages using the Distributed Network Protocol (DNP) V3.00 Data Link protocol and the DNP V3.00 Transport Functions.	560	
	B014-1N	WESMAINT II+ for D20MX	RTU maintenance facility.	620	Yes

License Group	D20MX Application ID	Application Name	Description	Application Definition Version	Changed
	B015	Bridgeman	Allows applications to communicate with other peer applications. Automatically routing messages to the destination application. Intended to work within layered software architectures. Provides the routing functions of a network layer, but does not add a network layer header to outgoing messages.	530	
	B023	DNP V3.00 DCA	The Distributed Network Protocol V3.00 DCA acts as the master to one or more remote devices using the DNP V3.00 protocol.	755	Yes
	B034-0N	Redundant Monitor for D20MX	Monitors CCU states and initiates failover. Also, receives command requests to perform database synchronization, switchover and failover.	300	Yes
	B045-0	D20AC WESMAINT II+ Display Screens	Provides D20AC WESMAINT II+ displays.	101	
	B052-0N	DNP Internet Data Link for D20MX	DNP V3.00 data link over internet.	351	
	B058-0	IEC 870-5 Data Link	FT 1.2 primary data link configuration	231	New
	B060-0	IEC 870-5-101 DCA	Acts as a master (primary) communication device, initiating data exchanges. It is capable of sending control commands to the remote devices, and processing data autonomously collected by the data link layer.	210	New
	B071-0	WESMAINT File Upload	Uploads files via the WESMAINT port as S records or using ZMODEM.	200	
	B085	IEC Balanced Data Link	Provides services to send and receive messages using the IEC 60870-5 FT 1.2 Balanced Protocol over point-to-point links, with support for a dial-up modem. Works with one user in point-to-point configurations, or multiple users in dial-up configurations.	130	New
	B086-0	IEC 60870-5-104 Data Link	Provides a service to reliably transfer IEC 60870-5-101 Application Service Data Units (ASDU) over a TCP/IP network. Implements this service using the transport layer interface protocol IEC 60870-5-104.	131	New
	B100-0	Internet Protocol Stack	Configuration of the LAN	141	
	B152-1N	IP Redundancy Monitor DTA for D20MX	Provides health and active pseudo DI points for LAN Ports.	200	Yes
SAN0001 Application Definitions					
	B009	Mailbox DTA	System point conversion application.	401	
	B021N	DNP V3.00 DPA for D20MX	The Distributed Network Protocol (DNP) DPA enables master stations to retrieve and modify local data using the DNP V3.00 Application Layer Protocol.	990	Yes
SAN0002 Application Definitions					
	B009	Mailbox DTA	System point conversion application.	310	
	B021N	DNP V3.00 DPA for D20MX	The Distributed Network Protocol (DNP) DPA enables master stations to retrieve and modify local data using the DNP V3.00 Application Layer Protocol.	913	Yes

Table 3 provides the License Group legend.

Table 3: D20MX license group

License Group	Group Description
001	D2X Classic Applications



The license group is an option in the D20MX order code. Refer to Table 10 and Table 11 for details. Ordering a D20MX with a particular license group option enables all applications in that group to run on the D20MX.

Table 4 lists the embedded images included in the D20MX firmware.

The **Version Image** column indicates the image versions in the SAN0001 and SAN0002 files.

Table 4: D20MX embedded images

Image ID	Image Name	Description	Version Image	Changed
S032	D20S Peripheral Board (supports B003)	D20S Peripheral Board Code	303	
S033	D20A Peripheral Board (supports B003)	D20A Peripheral Board Code	301	
S034	D20K Peripheral Board (supports B003)	D20K Peripheral Board Code	306	
S035	D20C Peripheral Board (supports B003)	D20C Peripheral Board Code	307	
S055-0	D20AC Peripheral Board (supports B003)	D20AC Peripheral Board Code	108	

Firmware/FPGA versions

Table 5 lists the firmware, FPGA and other version information.

Table 5: Firmware/FPGA versions information

Component	Version	ID Type	ID	Date	How to Find
JMON	1.0.630-2238	N/A	N/A	Wed Dec 12, 2012 11:06AM	"D20 Version" shown during cold boot sequence.
Board	N/A	Board	D20MX	N/A	"Board ID" shown via SHELL command: si
Local Bus FPGA	3.02	N/A	N/A	N/A	"FPGA version" shown via SHELL command: si
NVRAM FPGA	15	File	N/A	N/A	"NVRAM Rev" shown via SHELL command: si
VxWorks O/S and BSP	v1.20	Build	33d61705e0e7a6e7	Jul 17 2013, 21:00:12	SHELL command: ver
Application	v1.20	Build	d9dc1bd692eedad4	Jul 17 2013 - 20:28:26	SHELL command: ver
Bootrom	v1.1/0	Build	55959fd4c8a2db7f	Mar 11 2013 15:50:15	SHELL command: ver

D20 chassis

For a detailed description of the D20 chassis options and components, refer to Familiarization chapter in the *D20/D200 Installation and Operation Guide*, 994-0078. The D20MX supports the two versions of the D20 chassis listed in Table 6.


Table 6: Types of D20 chassis

Type	GE part number	Description
D20 non-VME 1 slot horizontal	500-0305	Chassis with backplane, external power connections, and seven serial I/O ports
D20 VME 5 slot horizontal	500-0280	Chassis with five-card VME backplane


D20 non-VME

The D20 non-VME single-slot chassis consists of the following:

- D20MX processor board
- Modem slots
- Power supply with switch and fuses; see Figure 1.


Figure 1: D20 non-VME chassis - power supply switch and fuses

This chassis contains the WESTERM D20M+ SS termination panel, which is attached directly to the back of the assembly; see Figure 2.

Figure 2: D20 non-VME backplane


D20 VME The D20 VME-compatible chassis (see Figure 3) can support one D20MX main board. When using the D20MX in a VME chassis, the 0 V ground wire must be used.

Figure 3: D20 VME chassis - power supply switch and fuses



This chassis (see Figure 4) contains the WESTERM D20M+ termination panel that is mounted separately on the D20 chassis. The VME chassis kit includes a VME bus backplane, called the WESTERM D20VME. The VME bus backplane connects to the termination panel using a ribbon cable from Slot 1 on the bus backplane.

Figure 4: D20 VME chassis - VME bus backplane and D20M+ termination panel



Power supply

The chassis-mounted power supply modules are switch-mode converters that provide output power for the D20MX processor board, VME cards, modems and D20 Peripheral I/O modules, as required. A redundant power supply can be installed to provide fail-over protection to ensure continuous power to the D20.

If you have an extended system with more than five peripherals, the chassis-mounted D20 power supply is not adequate. In this case, you need to install an external power supply.

Table 7 lists the standard power supplies that are available. Other power supplies are available for specific requirements. Contact GE Digital Energy for details.

Table 7: Available power supplies


GE part number	Input	Output
580-2004	20 to 60 V DC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 24 V DC, 3 A
580-2005	20 to 60 V DC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 48 V DC, 1.5 A
580-2006	100 to 300 V DC or 85 to 264 V AC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 24 V DC, 3 A
580-2007	100 to 300 V DC or 85 to 264 V AC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 48 V DC, 1.5 A

NOTICE

Ensure your D20 power input is externally protected for over-current; otherwise damage to the D20MX may occur. The required fuse rating depends on the power consumption of your system.

The D20 available power supplies, listed in Table 7 are equipped with two field replaceable fuses; see Figure 5.

Figure 5: D20 - Location of field-replaceable fuses



Field-replaceable fuses for the standard chassis-mounted Power Supplies are listed in Table 8. These are the standard factory-installed fuses, unless otherwise specified. Always replace with the same type and values of fuse.

Table 8: Field-replaceable fuses

Power Supply	Fuse	Fuse Function	Replacement Fuse ($\frac{1}{4}$ inch by 1 $\frac{1}{4}$ inch Time Delay)
580 - 2004	F1	+DC Input	12 A / 250 V
	F2	-DC Input	12 A / 250 V
580 - 2005	F1	+DC Input	12 A / 250 V
	F2	-DC Input	12 A / 250 V

Power Supply	Fuse	Fuse Function	Replacement Fuse (½ inch by 1 ¼ inch Time Delay)
580 - 2006	F1	Line/+DC Input	4 A / 250 V
	F2	Neutral/-DC Input	4 A / 250 V
580 - 2007	F1	Line/+DC Input	4 A / 250 V
	F2	Neutral/-DC Input	4 A / 250 V

Modems

D20 modems (can be purchased separately) for communications to a host computer or to other IEDs.

For example, WESDAC 202/V.23 is a 1200-baud Bell 202 or CCITT V.23 standard modem designed for 300 to 1200 baud asynchronous operation on unconditioned lines and supports the majority of SCADA/EMS applications. It is available in a 3U (GE part number 520-0120) vertical mount configuration in the D20 chassis; the 19 inch rack mount (GE part number 520-0090) version is currently not supported.

Third-party modems can be used to meet specific requirements. These modems are connected to the D20 via standard RS-232 connections. Contact GE Digital Energy for more information on options.

Peripherals

Peripheral I/O modules are intelligent modules containing an on-board microprocessor. They are configured as slaves to the D20MX processor board. In this way, specific I/O processing is distributed throughout the RTU to the appropriate I/O module.

There are five types of I/O peripherals:

- D20A analog input
- D20S digital inputs
- D20K digital output
- D20C combination input/output
- D20AC alternating current analog input

Optional high-voltage peripherals are also available.

The D20MX is only compatible with certain peripheral common code (i.e., pcommon) versions as defined in Table 9.

Table 9: PCOMMON versions compatible with the D20MX

PCOMMON Description	Version Compatibility with D20MX
P022 - PCOMMON for D20C	3.05, 3.00 are compatible
	2.21 and earlier are NOT compatible
P010 - PCOMMON for D20A, D20S and D20K	3.06, 3.05, 3.01, 3.00 are compatible
	2.21 and earlier are NOT compatible
P087 - pBOOT for D20AC	1.04, 1.03, 1.02 are compatible

Ordering guide

The latest D20MX Processor ordering guide is available on the GE Digital Energy website:

<http://www.gedigitalenergy.com/multilin/energy/catalog/D20MX.htm>

You can select the required options from the available Product Option items. The Order Code automatically updates as each option is selected.

The Order Codes are listed in Table 10.

Table 10: D20MX order codes

D20 MX CPU Options	D20 MX	-C	P	M	M	M	P	F	L	U	U	U
(A) - D20MX non-VME, dual 10/100/1000BASE-TX Ethernet Ports (front access)		A										
(C) - D20MX non-VME dual 100BASE-FX Ethernet Ports (front access)		C										
(G) - D20MX non-VME, dual 100BASE-FX Ethernet Ports (rear access)		G										
D20 MX CPU Options												
(U) - Not required		U										
(A) - D20 Power Supply, 20-60VDC Input, 24V ISO Output		A										
(B) - D20 Power Supply, 20-60VDC Input, 48V ISO Output		B										
(C) - D20 Power Supply, 100-300VDC/85-264VAC Input, 24V ISO Output		C										
(D) - D20 Power Supply, 100-300VDC/85-264VAC Input, 48V ISO Output		D										
D20MX Modem slots 1, 2 & 3												
(U) - Empty slot with cover plate				U	U	U						
(A) - Wesdac D20 202 bin modem				A	A	A						
(C) - Telenetics 14400 baud modem 2-wire dial up				C	C	C						
(D) - Telenetics 14400 baud modem 4-wire leased line				D	D	D						
(E) - D20MX dual 100BASE-FX ST Media Interface Card				E								
(F) - D20MX dual 100 BASE-FX LC Media Interface Card				F								
D20MX Serial Termination Panel Options												
(A) - 19" Rack Mount Serial IO Western Panel							A					
(B) - D20 Chassis Mounted Serial IO Western Panel							B					
(C) - D20 Chassis Mounted Serial IO Western Panel w/Extended Bracket							C					
D20MX firmware options												
(B) - D20MX firmware v1.20								B				
D20MX D2X CLASSIC APPLICATIONS License												
(U) - Not required									U			
(A) - D2X CLASSIC APPLICATIONS									A			
FUTURE Feature												
(U) - Not required										U		
FUTURE Feature												
(U) - Not required											U	
FUTURE Feature												
(U) - Not required												U

D20MX upgrade kits

Table 11 provides the available D20MX upgrade kits and spare kit (D20MX CPU only) Order Guide. Order GE part number 588-0082: SGConfig Setup Software DVD if required.

Table 11: D20MX upgrade kits order guide

D20MX Kit Type	D20MXK	-A	C	M	F	L	U	U	U
(A) - Upgrade Kit for D20 Horizontal chassis		A							
(C) - D20MX CPU only		C							
D20MX CPU Options									
(A) - D20MX non-VME, dual 10/100/1000BASE-TX Ethernet Ports (front access)		A							
(C) - D20MX non-VME dual 100BASE-FX Ethernet Ports (front access)		C							
(G) - D20MX non-VME, dual 100BASE-FX Ethernet Ports (rear access)		G							
D20MX Media Interface Card Options									
(U) - Not required				U					
(E) - D20MX dual 100BASE-FX ST Media Interface Card				E					
D20MX firmware options									
(B) - D20MX firmware v1.20					B				
D20MX D2X CLASSIC APPLICATIONS License									
(U) - Not required						U			
(A) - D2X CLASSIC APPLICATIONS						A			
FUTURE Feature									
(U) - Not required							U		
FUTURE Feature									
(U) - Not required								U	
FUTURE Feature									
(U) - Not required									U

Table 12 lists the parts provided in each D20MX upgrade kit.

Table 12: Upgrade kit parts

Part Number	Part Description	D20MXK-AAUXXUUU	D20MXK-ACUXXUUU	D20MXK-AGEXXUUU
526-3001	D20MX CPU non VME 2x10/100/1000 BaseTX	1		
526-3003	D20MX CPU non VME 2x100 BaseFX (Front Access)		1	
526-3005	D20MX CPU non VME 2x100 BaseFX (Rear Access)			1
526-3104	D20MX 100Base-FX Rear ST FO Card			1
975-1236	D20MX CPU to D20MX Rear FO Card Harness			1
975-1237	Termination panel to Backplane 0 V Harness	1	1	1
953-1014	Blank Plate for D20MX Install	1	1	1
953-1015	Lower filler cover plate	1	1	1
581-0002	GE Digital Energy Products Documentation CD	1	1	1
588-0075 V120	GE Digital Energy D20MX Documentation CD	1	1	1
977-0529/72	Cable, Null Modem DB9F-DB9F, 80 °C, 150 V	1	1	1
460-0073	Ferrite clamp	1	1	1

Table 13 lists the parts provided in each D20MX spare kit.

Table 13: Spare kit parts

Part Number	Part Description	D20MXK-CAUXXUUU	D20MXK-CCUXXUUU	D20MXK-CGEXXUUU
526-3001	D20MX CPU non VME 2x10/100/1000 BaseTX	1		
526-3003	D20MX CPU non VME 2x100 BaseFX (Front Access)		1	
526-3005	D20MX CPU non VME 2x100 BaseFX (Rear Access)			1

Product specifications

The D20MX adheres to the following system, communications, electrical, physical and environmental specifications. Additional Standards and Protection are listed in Appendix A, *Standards & Protection*.

System

Processor	667 MHz embedded PowerQUICC II Pro
Memory	1024 MB of 266 MHz DDR2 RAM with ECC 16 MB NVRAM for persistent event storage
Storage	8 MB boot flash 256 MB firmware flash
Operating system	VxWorks
LED indicators	System status: Power, Ready Ethernet port status: Link and Activity status per port Power supply: Power IRIG: Flashes when active.

Communications

Network connections	Dual redundant Ethernet interface Twisted Pair 10/100/1000BaseT (Isolated RJ-45 connector) 100BaseFX (Fiber Optic: 1300 nm, 50/125 μ m, 62.5/125 μ m multi-mode duplex fiber cable, ST connectors)
Serial communications	D.20 Link, 2 channels Data rate: 250 kbps Surge protected to ± 2000 V peak RS-232, 7 channels 5-signal (TXD, RXD, RTS#, CTS#, DCD#) DTE ports Data rate: independently-selectable; refer to the application configuration guides.
Maintenance Port	RS-232, 1 channel/ 2 ports 2-signal (TXD, RXD) Data rate: 19200 (default)

Electrical

Rated power supplies	AC-DC	100 to 240 V AC ($\pm 10\%$) 143 W output maximum Minimum/Maximum AC voltage: 90 V AC / 265 V AC 100 to 300 V DC ($\pm 10\%$) 143 W output maximum Minimum/Maximum DC voltage: 88 V DC / 330 V DC
	DC-DC	20 to 55 V DC ($\pm 10\%$) 135 W maximum Minimum/Maximum DC voltage: 18 V DC / 60 V DC
Peak inrush current at 25 °C on cold start	AC-DC	50 A, max at 230 V AC
	DC-DC	50 A, max at 230 V AC
Rated frequency (AC-DC)	50/60 Hz nominal (47 to 63 Hz)	

Physical

Overall height	40.34 mm (1.588 in.)
Width	261.87 mm (10.31 in.)
Depth	160 mm (6.3 in.)
D20MX weight	0.7 kg (1.65 lb)
Fiber card weight	0.2 kg (0.35 lb)
Battery shipping restrictions	The D20MX does not contain a battery and is therefore not affected by US DOT or ICAO shipping restrictions.
Material/Finish	Galvannealed steel with black power coat
Kit package	Length: 49.5 cm (19.5 in.) Width: 34.3 cm (13.5 in.) Height: 15.2 cm (6 in.) Weight: 2.54 kg (5.6 lb)

Environmental

Operating temperature	0°C to +70°C Note: Do not operate the D20MX above 60°C for extended periods of time as this will shorten the life of the super capacitor and reduce the backup time of the real time clock.
Humidity rating	5% to 95% relative humidity, non-condensing
Environmental rating	Ingress protection: IP30 (IEC 60529)
Installation / overvoltage category	CAT II (2)
Pollution degree	2
Use	Indoor use only
Operating altitude	Maximum altitude 3000 m [9480 feet] above sea level
MTBF (MIL-HDBK-217): D20MX processor board	Non-VME with 10/100/1000BASE-TX copper: 449,616 hours at 40°C Non-VME with 100BASE-FX fiber optic: 265,657 hours at 40°C

Software

Configuration	Performed using SGConfig 7.2 and higher
----------------------	---

SOE time stamp accuracy

Time Sync	IRIG-B
Test	Status point on D20S peripheral toggled at 1 pulse per second, synchronized to a GPS time signal. D20MX running under load.
Performance	99% of 1 pulse per second events are within ± 1 ms, and 100% of the events are within ± 2 ms over a 15 hour period

Storage recommendations

Storage conditions

Always store the D20MX in an environment compatible with operating conditions.

Recommended environmental conditions for storage are:

- Temperature: -40 °C to +85 °C
- Relative humidity: 5% to 95%, non-condensing
- Maximum altitude: 12192 m [40,000 feet] above sea level



Do not store the D20MX above 60°C for extended periods of time as this will shorten the life of the super capacitor and reduce the backup time of the real time clock.

When powered off, the D20MX real time clock will remain active for 14 days at -40°C to 60°C, and greater than one month at 25°C. Information in the NVRAM will remain stored indefinitely since flash memory is used.

D20MX Processor

Chapter 2: Installing the D20MX

This chapter covers the following topics:

- D20 chassis layouts
- Overview of the steps and tools required to install the D20MX
- Retrofitting the D20MX in an existing D20
- Grounding the D20MX and connecting the power supply

D20 chassis layouts

Installation of the D20MX can be performed with one of three D20 chassis layouts; see “Installation steps” on page 33.

The D20 non-VME chassis front panel layouts for the D20MX upgrade kits comprise:

- A D20 containing a D20MX with front Ethernet connectors; see Figure 6.
- A D20 containing a D20MX with front Fiber Optic connectors; see Figure 7.
- A D20 containing a D20MX with rear Fiber Optic connectors; see Figure 8.




Figure 6: D20 chassis front panel - D20MX with Ethernet connectors**Figure 7: D20 chassis front panel - D20MX with front fiber optic connectors**

Figure 8: D20 chassis front panel - D20MX with rear fiber optic connectors



Installation steps

The D20MX can be installed in a non-VME (GE part number 500-0305) or VME (GE part number 500-0280) D20 chassis. If you are retrofitting an existing D20 device, See section: "Retrofitting the D20MX in an existing D20" on page 35.

To install the D20MX in a D20 chassis

1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: "Grounding the D20MX" on page 38.
2. Remove the D20MX from its static-protective packaging. Set the packaging aside and save it for future reuse. See section: "Unpacking the D20MX" on page 38.



The D20MX must be placed on an anti-static surface while not installed in the chassis.

3. Remove all horizontal blank faceplates.
4. Gently install the D20MX in the first (bottom-most) slot. Align the edge of the D20MX with the guide rails in the D20 chassis.



The D20MX is a double-height board that occupies two slots in the chassis. Handle the D20MX with care, since SMT components are located on the bottom side.

5. Push the front panel of the D20MX until it is seated properly and firmly connected to the backplane of the chassis.
6. Tighten the front panel retaining screws to 3.5 in-lbs to secure the D20MX to the chassis.
7. For the 526-3005LF version:
 - 7.1. Remove the position 1 and position 2 vertical blank plates from the D20 chassis.
 - 7.2. Remove the D20MX Fiber Card from the static-protective packaging.

- 7.3. Connect the 20-pin header end of the cable (part number 975-1236) to connector P1 on the fiber optic daughter card.
- 7.4. Secure the cable to the fiber optic daughter card with a cable tie.
- 7.5. Insert the fiber optic daughter card partially into the chassis, and feed the other ends of the cable through the middle slot in the chassis wall between the VME slots and the peripheral slots.
- 7.6. Connect the other end of the cable (with two connectors) to the D20MX connectors J3 (shorter length of cable) and J4 (longer length of cable). See Figure 11, "Cable to fiber optic daughter card," on page 36. Ensure that the cable is not pinched.
- 7.7. Push the front panel of the fiber optic daughter card until it is fully inserted.
- 7.8. Tighten the front panel retaining screws to 3.5 in-lbs to secure the fiber optic daughter card to the chassis.
8. Install the new lower filler plate (part number 953-1015).
9. Install the new filler plate (part number 953-1014) in the space above the D20MX.
10. Attach any required communication cables to the connectors on the front panel of the D20MX or the backplane of the D20 chassis.
11. If the D20MX is being installed in a VME chassis, connect the 0 V cable (part number 975-1237):
 - 11.1. Connect the bare end of the cable wire to the 0 V connector on the WESTERM terminal block TB2-9.
 - 11.2. Remove the wire from the lower 0 V connector on the VME backplane and connect this wire to the male end of the 0 V cable.
 - 11.3. Connect the female end of the 0 V cable to the lower 0 V connector on the VME backplane.


See Figure 12, "0 V cable connection".
12. Install the ferrite clamp.

If you ordered a complete D20 system including the D20MX with power cable, notice that a ferrite clamp has already been attached to the power cable. Go to step 13.

If you ordered a D20MX upgrade kit or a D20 system without power cable, a ferrite clamp included in the package is to be attached to the power inlet cable:

 - 12.1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See "Grounding the D20MX" on page 38..
 - 12.2. Remove ferrite clamp (GE part number 460-0073) from the package; handle with care as the magnetic material is fragile.
 - 12.3. Pass the power cable through the channel, approximately 15 cm (6 inches) from the connector on the chassis.
 - 12.4. Loop the power cable one more time around and through the core. See Figure 9.

Figure 9: Open ferrite clamp



12.5. Close the core and snap the halves together. See Figure 10.

Figure 10: Closed ferrite clamp



- 12.6. Visually inspect the installation and confirm that the assembly has completely latched and that the power cable is not pinched. Also check that none of the power cable connections have come loose during the installation process.
13. Connect the power supply to the D20 chassis. See section: "Connecting the power supply" on page 38.
 14. Power-up the D20. See Chapter 4, *Powering-up and Testing*.
 15. Start using the D20MX's tools and utilities to configure and monitor the operation of the D20MX. See Chapter 6, *Using the D20MX*.
 16. Make device and network connections. See Chapter 3, *Connecting to Devices and Networks*.

Retrofitting the D20MX in an existing D20

The D20MX processor board can be installed in an existing D20 device to replace D20ME, D20M++, or D20MEII processor boards. If a D20 is being retrofitted, the following limitations exist:


- You cannot install multiple D20MX processor boards in a single D20. Therefore, a maximum of seven serial and two D.20 Link connections are supported on each D20 unit.
- The D20MX supports 100BASE-FX instead of 10BASE-FL. If you are using any other devices in your system, and you are limited to 10BASE-FL, you must purchase a 100BASE-FX to 10BASE-FL media converter.

The D20MX can be installed in a VME chassis or a non-VME chassis.

See section: "D20MX upgrade kits" on page 25 for a list of available upgrade kits and the parts provided within each kit.

To retrofit the VME chassis and the non-VME chassis


1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: "*Grounding the D20MX*" on page 38.
2. Switch the power off for the D20 chassis.
3. Remove the D20ME, D20M++, or D20ME II module.
4. Remove the D20EME module and D20EME Media Interface Card.
5. Remove the horizontal blank faceplates, including the bottom faceplate.
6. If the chassis contains a modem card, move the modem card to position 2.
7. Follow the D20MX "Installation steps" on page 33.
See Figure 11, "*Cable to fiber optic daughter card*".
Ensure that the cable is not pinched.

Figure 11: Cable to fiber optic daughter card

8. If the D20MX is being installed in a VME chassis, connect the 0 V cable (part number 975-1237):
 - 8.1. Connect the bare end of the 0 V cable wire to the 0 V connector on the WESTERM terminal block TB2-9.
 - 8.2. Remove the wire from the lower 0 V connector on the VME backplane and connect this wire to the male end of the 0 V cable.
 - 8.3. Connect the female end of the 0 V cable to the lower 0 V connector on the VME backplane.

See Figure 12, "0 V cable connection".

Figure 12: 0 V cable connection



Required tools and materials

Before beginning the installation procedures, have the following tools and equipment available:

- Appropriate device cables for D.20 connections (GE part number 977-0089)
- For D20MX Non-VME with Dual 10/100/1000Base-TX (part number 526-3001): CAT5 network cables for RJ-45 Ethernet connections (GE part number 977-0280 or equivalent)
- For D20MX Non-VME with Dual 100Base-FX (part number 526-3003) and D20MX Non-VME with Dual 100Base-FX Fiber Optic Card (part number 526-3005): multi-mode duplex fiber cable - ST connectors.
- Flathead screwdriver with 0.6 mm by 3.5 mm blade (for terminal block wiring)
- #1 Phillips screwdriver (for panel or DIN rail mounting the unit)
- #2 Phillips screwdriver (for rack mounting the unit)
- Needle-nose pliers
- Wire cutters
- Wire strippers
- Approved network settings for the device
- Windows-based PC with any Windows-based terminal emulation software and Web browser software installed
- 12 AWG wire (minimum) for protective earth
- 2 ring connectors, Panduit part number PV10-14R for 12 AWG [3.3 mm²] wire for protective earth terminal

Grounding the D20MX

Surge and noise suppression components used on the D20MX are designed to prevent nuisance operation and damage to internal components. To ensure correct protective operation, the earth ground wire (14AWG green wire) on the D20 chassis must be connected to a low impedance ground rail of a secondary cabinet or rack.

When making ground connections, ensure that all surfaces that are used for grounding are free of dirt, residue and corrosion.

Do not power up the D20 before establishing a proper protective earth connection.

NOTICE

Unpacking the D20MX

Carefully remove the D20MX from its packaging. Visually inspect the unit to ensure it has not sustained any visible damage during transit. If there are visible signs of damage, *report it immediately to the carrier.*

Package contents

The following items are provided as part of your D20MX shipment:

- D20MX unit (GE part number 526-3001, or 526-3003, or 526-3005)
- For 526-3005LF only:
 - D20MX to Fiber Card Harness (975-1236)
 - D20MX 100BASE-FX Rear LC FO Card (part number 526-3103LF) or D20MX 100BASE-FX Rear ST FO Card (part number 526-3104LF)
- Lower filler plate (part number 953-1015)
- Blank plate for D20MX install (part number 953-1014)
- 0 V wire cable (part number 975-1237)
- For 526-3005LF installed in 500-0280 only:
 - Termination Panel, D20MX extended mounting (952-2087)
- GE Digital Energy Product Documentation CD (GE part number 581-0002)
- GE Digital Energy D20MX Documentation CD (GE part number 588-0075 V120)

Verify that you have received all items. GE parts include a unique number, typically in the format XXX-XXXX, that can be used as a reference.


Connecting the power supply

The D20MX processor board is supplied power through the WESTERM D20M+ SS backplane. Power connections to the backplane are made on connector block TB1. For the WESTERM D20M+ SS and WESTERM D20M+ (see Figure 13, “WESTERM D20M+SS: power supply connections”) the power supply connections:

- 1 and 2 are used for input power connections based on the D20 power supply
- 4 and 5 can be used as a switched auxiliary power supply source

- 7 and 8 can be used externally for status wetting, contact wetting and/or miscellaneous power connections, if applicable.

Figure 13: WESTERM D20M+SS: power supply connections



D20MX Processor

Chapter 3: Connecting to Devices and Networks

This chapter provides guidelines for making physical connections between the D20 and substation and network devices.

Cabling overview

All physical connections are made to the connectors on the rear backplane of the D20 chassis or to the front on the D20MX processor module.

D20MX front panel connectors

The D20MX front panel can have one of the following layouts:

- Ethernet connectors (RJ45); see Figure 14.
- Front access Fiber optic connectors (ST); see Figure 15.
- Rear access Fiber optic connectors (ST) on a fiber optic daughter card; see Figure 16.

For a description of the operational status LEDs and port status LEDs, see “Front panel LEDs” on page 85.

Figure 14: D20MX front panel with Ethernet connectors




Figure 15: D20MX front panel with front access fiber optic connectors





Figure 16: D20MX front panel and fiber optic card with rear access fiber optic connectors



General cabling requirements

Table 14 lists the cables required to connect to the D20MX:

Table 14: Connection cables

Media	Designation	Cabling	Connector
Serial	RS-232	Shielded	DB-9 female
D.20 Link	RS-485 2 wire	Shielded	DB-9 female
Twisted Pair Ethernet (GE part number 526-3001 only)	10/100/1000BASE-T	UTP (Unshielded Twisted Pair) – CAT 5 or better	RJ-45
Fiber optic (GE part number 526-3003 and 526-3005LF only)	100BASE-FX	1300 nm, 50/125 μ m and 62.5/125 μ m multimode duplex fiber cable	ST-style connectors

To provide higher EMC immunity and maintain CE Mark radiated emission compliance, the serial cables used for permanent serial and D.20 Link connections must comply with the following requirements:

- Cables must be shielded
- D-type connector covers must provide EMC shielding (e.g. metallized plastic or die cast metal covers).

Serial

Seven serial communications ports are brought out to the backplane connector P2. These serial ports are five-signal (TXD, RXD, RTS#, CTS#, DCD#) DTE serial ports, compliant to ANSI/TIA-232 and TIA/EIA-694 specifications and are hosted by UARTs.

The D20MX is tested with all 7 serial ports running at 19200 baud with 20% CPU utilization. Refer to application configuration guides for supported baud rates and for data bits.

NOTICE

To avoid burning out the WESTERM or D20MX mainboard when directly connecting a rear-panel serial port on one D20MX chassis to another rear-panel serial port on any type of D20 chassis, jumper the WESTERM of both chassis' to not provide a power connection to pin 4. Refer to the appropriate WESTERM module layout for jumper settings.

D.20 Link

Communications between the D20 and the D20 peripheral I/O modules are carried over a high-speed, high-level data link control (HDLC) protocol called the D.20 Link. The D.20 Link has the following features:

- RS-485 serial link, half duplex, 250 kbps
- D.20 frame using HDLC protocol format with Manchester encoding
- Supports up to 38 D20 I/O peripheral modules in a standard configuration

Twisted-pair Ethernet (for 526-3001 only)

The 10/100/1000BASE-T variant of the D20MX can connect to one or two networks through two twisted-pair Ethernet connections. In single-IP mode this causes the two Ethernet connections to use the same MAC address and IP address. Port 1 is the primary port and Port 2 is the secondary port. When the system detects a signal on Port 1, Ethernet traffic takes place on Port 1. When the system detects loss of signal on Port 1, Ethernet traffic takes place on port 2.

All RJ-45 connectors have the same signal definition. However, the twisted-pair Ethernet ports are auto MDI/MDIX and can support a straight-through or crossover cable.

External switches must have Spanning Tree Protocol port settings configured to edge for proper operation.



NOTE

To connect the D20MX to network devices



NOTE

Plug network cables into the D20MX twisted-pair Ethernet ports.

If the D20MX is deployed in the presence of strong RF energy in the 110 MHz - 125 MHz band, such as airport ILS localizers or aviation radio transmitters, it is recommended that shielded twisted-pair Ethernet cables be used.

Table 15: Ethernet RJ-45 connector signal definitions

Position	Function	Signal Flow	Color
1	RX+	IN	White w/ Orange
2	RX-	IN	Orange
3	TX+	OUT	White w/ Green
4	P1+	-	Blue
5	P1-	-	White w/ Blue
6	TX-	OUT	Green
7	P2+	-	White w/ Brown
8	P2-	-	Brown
	Shield	-	-

Table 16: Ethernet crossover cable (RJ-45) pin out

D20MX		Switch/Hub	
Name	Pin	Pin	Name
TX_D1+	1	3	RX_D2+
TX_D1-	2	6	RX_D2-
RX_D2+	3	1	TX_D1+
RX_D2-	4	2	TX_D1-
BI_D3+	5	7	BI_D4+
BI_D3-	6	8	BI_D4-
BI_D4+	7	4	BI_D3+
BI_D4-	8	5	BI_D3-

Table 17: Ethernet straight-through cable (RJ-45) pin Out

D20MX		PC	
Name	Pin	Pin	Name
TX_D1+	1	1	RX_D2+
TX_D1-	2	2	RX_D2-
RX_D2+	3	3	TX_D1+
RX_D2-	4	4	TX_D1-
BI_D3+	5	5	BI_D4+
BI_D3-	6	6	BI_D4-
BI_D4+	7	7	BI_D3+
BI_D4-	8	8	BI_D3-

Fiber optic Ethernet (for 526-3003 and 526-3005LF only)

The 100BASE-FX variant of the D20MX (GE part numbers 526-3003 and 526-3005) can connect to one or two networks through two fiber-optic Ethernet connections. The data rate on each port is 100 Mbps.



You must enable Far End Fault Indication (FEFI) or Loss Link Alert (LLA) in connected external devices for proper redundant operation.



External switches must have Spanning Tree Protocol port settings configured to edge for proper operation of 100Base-FX connected ports.

You can use the following glass optical fiber (GOF) cabling with the D20MX:

- 50/125 μm core/cladding multi-mode (gradient index) cable
- 62.5/125 μm core cladding multi-mode (gradient index) cable
- 100/140 μm core/cladding multi-mode (gradient index) cable
- 200 m core Hard-Clad Silica (HCS) multi-mode (step index) cable

You can use the following fiber optic terminations for D20MX cabling:

- ST Connectors (with 526-3003 and 526-3005LF + 526-3104LF fiber card)
- LC connectors (with 526-3005LF + 526-3103LF fiber card)

When calculating cable length, consider the following optical power levels:

- Glass optical fiber transmitter power is -19.0 ± 2 dBm
- Glass optical fiber receiver sensitivity is typically -25.4 dBm



This product contains components rated as Class 1 Laser Products.

LAN redundancy

Both twisted-pair and fiber optic Ethernet options provide two LAN redundancy schemes called single-IP redundancy and dual-IP redundancy.

Single-IP redundancy provides automated fail over between two Ethernet network connections (TX1/RX1 and TX2/RX2) that share a single MAC and IP address.

When the primary port (that is, port 1) receives no signal, or detects a fault signal from the remote link partner, the D20MX switches to the secondary port (that is, port 2) if it has a valid link. The D20MX reverts to the primary port if the primary link is restored or no signal is present on the secondary port.

With dual-IP redundancy, each port has a unique MAC, IP address and subnet. Each remote device participating in dual-IP redundancy must have a primary IP address reachable through the subnet of port 1 of the D20MX and a secondary IP address reachable through the subnet of port 2 of the D20MX. D20MX client applications will fail over to the remote device's secondary IP address when they detect a failure to communicate with the remote device's primary IP address. D20MX server applications accept communications from the remote device's primary or secondary IP address.

To configure a system for single-IP redundancy, enable only LAN A in the device properties of the D20MX. To configure a system for dual-IP redundancy, enable both LAN A and LAN B in the device properties of the D20MX. The D20MX device properties may be configured through SGConfig 7.2 and higher.

IP addresses

The D20MX assigns IP configuration to its LAN A and optionally LAN B interface according to the rules defined in Table 18.

In a standalone system, the D20MX assigns the LAN A and LAN B IP addresses exactly as you configured them in SGConfig.

In a redundant system, the D20MX assigns the LAN A and LAN B IP addresses of the Active CCU exactly as you configured them in SGConfig.

However, in other modes, the CCU assigns derived IP addresses as indicated in Table 18. For a description of the modes, refer to Table 20. The D20MX assigns the subnet mask of the derived IP addresses as the subnet mask configured in the LAN A or LAN B configuration.


Table 18: D20MX IP address assignment

CCU	Redundant System	Mode	LAN A IP Configuration	LAN B IP Configuration (If Configured)
CCU A	Standalone	Active, Debug or Disabled	IP Address: LAN A IP Address	IP Address: LAN B IP Address
CCU A	Redundant	Active	Mask: LAN B Subnet Mask (e.g. 192.168.1.1 / 255.255.255.0)	Mask: Configured LAN B Subnet Mask (e.g. 192.168.2.1 / 255.255.255.0)
CCU B	Redundant	Active		
CCU A	Redundant	Standby, Debug or Disabled.	Derived IP Address: LAN A IP Address + 1 Mask: LAN A subnet mask (e.g. 192.168.1.2 / 255.255.255.0)	Derived IP Address: LAN B IP Address + 1 Mask: LAN B subnet mask (e.g. 192.168.2.2 / 255.255.255.0)

CCU	Redundant System	Mode	LAN A IP Configuration	LAN B IP Configuration (If Configured)
CCU B	Redundant	Standby, Debug or Disabled.	Derived IP Address: LAN A IP Address + 2 Mask: LAN A subnet mask (e.g. 192.168.1.3 / 255.255.255.0)	Derived IP Address: LAN B IP Address + 2 Mask: LAN B subnet mask (e.g. 192.168.2.3 / 255.255.255.0)
CCU A/B	Redundant or Standalone	Service Mode	Not enabled	Not enabled

You may override or disable the derived IP address by defining a host with the desired IP address. Use an IP address of 0.0.0.0 to disable the derived IP address. Define the host in the SGConfig tool > D20 Device Wizard > Define the LAN properties for this project screen (see Figure 17 for an example).

Figure 17: SGConfig - example of overriding derived IP address by defining a hostname



Each host consists of a host name and host address. Construct the host name by replacing the last two characters of the D20 Host Name with a two character suffix that matches the derived IP address you wish to override or disable. The suffix conventions are shown in Table 19. The D20 Host Name appears in the D20 Device Wizard as shown in Figure 18.

Figure 18: SGConfig - Host name shown in the LAN Settings




Table 19: Host name suffix conventions

HostName Suffix	IP Address Corresponds To...	Example
AA	CCU A, LAN A	FAC_DEF_AA
AB	CCU A, LAN B	FAC_DEF_AB
BA	CCU B, LAN A	FAC_DEF_BA
BB	CCU B, LAN B	FAC_DEF_BB

The D20MX can be in one of five modes as defined in Table 20. You can find the current mode of the D20MX by navigating to the SHELL in WESMAINT II+ and typing the command **el**.

Table 20: System mode definitions

Mode	Description	Partial "el" output
Active	D20MX applications are operational.	Active CCU YES
Standby	D20MX applications are not operational but are ready to take over on a switchover command or a failover.	Standby CCU YES
Disabled	D20MX applications have been suspended due to an error. You must type el /r and boot in the SHELL to clear this error.	Disabled YES
Debug	D20MX boot sequence has been interrupted by pressing CTRL-E . Put the CCU into this mode in order to recover a system that has a corrupted configuration or code image.	Redundant CCU NO Standby CCU NO Active CCU NO Service Mode NO Sys Service Mode NO Disabled NO
Service Mode	D20MX configuration has been corrupted or is in the process of receiving a new configuration. To recover the system, you must download a configuration serially.	Service Mode YES

RS-232

The RS-232 port on the D20MX is used to access the WESMAINT II+ facility and to transfer code and configuration data to the D20MX. You can use a VT100-compatible terminal or terminal emulation program to directly access the WESMAINT II+ facility. SGConfig's Terminal Emulator is an example of a suitable terminal emulation program.

The RS-232 port is connected to the D20MX front panel and is also routed to the rear panel as (COM0). The default baud rate is 19,200.

Non-responsive RS-232 port

In the event that the D20MX RS-232 port appears non-responsive, type **Ctrl-Q**. This non-responsive condition might occur if your computer goes into sleep mode and then wakes up while still connected to the D20MX RS-232 port.

NOTICE

Use only a NULL modem cable (GE Energy part number 977-0529) when you are connecting to the D20MX front-panel RS-232 connector. Use of a WESMAINT cable will not allow communication to the D20MX.

NOTICE

Use only a standard WESMAINT cable (GE Energy part number 977-0300) when connecting to the rear panel COM0 connector. Use of a NULL modem cable will cause permanent damage to the D20MX and PC.

D20 system redundancy

A redundant D20 setup allows a secondary D20 to automatically take over operations from a paired D20 unit that has failed.

D20 equipment redundancy requires:

- Two D20 units and
- One or two RS-232 switch panels.




NOTE

The quiescent current of the +12 V power supply input on the RS-232 Switch Panel is 15 mA. The maximum power requirement on the +12 V input during operation is 230 mA.

Through a toggle switch on the RS-232 Switch Panel, you designate one of the CCUs as the Active unit. If the Active unit hardware or software fails, the Active CCU is automatically switched offline, and the Standby unit is switched through to the field equipment (i.e., it is made Active).

The RS-232 Switch Panel is not equipped with EMI protection circuitry. If the connection length exceeds 3m, a Serial Surge Protection Panel (GE item number 540-0249) or equivalent protection device should be installed.

Figure 19 shows a redundant D20 system, with CCU A active.

Figure 19: Redundant D20 system with CCU A active

If the Active CCU fails:

- The Standby CCU detects the failure through the inter-CCU communications link.
- The Standby CCU commands the RS-232 Switch Panel to switch over all serial connections.
- The RS-232 Switch Panel switches all serial field connections to the Standby CCU, which now becomes the Active CCU.

If CCU A fails, CCU B becomes active. See Figure 20, "Redundant D20 system - If CCU A fails".



Figure 20: Redundant D20 system - If CCU A fails

Figure 21: RS-232 Switch panel

A pair of LEDs marked *CCU A* and *CCU B* indicate which of the D20 units is currently active. If the hardware or software of the active unit fails, it is automatically switched offline and serial connections to the field are transferred to the standby unit. A toggle switch on the RS-232 switch panel can be used to switch the D20 devices between active and standby modes.

Failover sequence

If the active D20 unit fails, the following actions occur:

1. The standby D20 unit detects the failure through the lack of a heartbeat signal on the ping cable or through a status change on the watchdog cable.
2. The standby D20 unit attempts to pull the RS-232 switch panel to assume the active state.
3. The RS-232 switch panel transfers all serial field connections to the standby D20, which then becomes the active D20.

Required components

To implement a redundant D20 system, you need the components: listed in Table 21.

Table 21: Redundant D20 system - required components

Component	Function	Part Number
RS-232 Switch Panel	Communications switch.	517-0247
Power Supply	Power supply to power the RS-232 switch panel. Input: 85 – 264 V AC or 90 – 350 V DC.	580-0046
Watchdog Cable Assembly	Connects D20 A to the RS-232 switch panel.	977-0160
	Connects D20 B to the RS-232 switch panel.	977-0160
Ping Cable Assembly	Links both D20 units to facilitate a heartbeat message that determines the status of the active unit.	977-0122
RS-232 Serial Cable	Connects the D20 to the RS-232 switch panel which is then connected to external field devices.	977-0121
Power/SysFail Cable	Connects the RS-232 switch panel to D20 external power supply.	970-0161
Ground Cable	Provides a ground connection for the RS-232 switch panel.	970-0182



NOTE

Pins 4 on switch panel connectors J2 through J9 are tied together and to the panel's power supply. Any loading from field devices on these pins will load the RS-232 panel power supply and should be taken into consideration when sizing power supplies.

To set up a redundant system

It is recommended that you install and configure one standalone D20 unit to ensure that your configuration is valid and that device communications are operating properly. Once this is done, proceed with the installation of the redundant system.

1. Mount the D20 units in a rack and connect power and ground.
2. Mount the RS-232 switch panel.
3. Plug the connector of watchdog cable A (GE part number 977-0160) to serial connector COM 6 on the first D20 (CCU A).
4. Connect the bare leads of watchdog cable A to TB1 (position 6-8) on the RS-232 switch panel.
5. Plug the connector of watchdog cable B (GE part number 977-0160) to serial connector COM 6 on the second D20 (CCU B).
6. Connect the bare leads of watchdog cable B to TB1 (position 14-16) on the RS-232 switch panel.
7. Connect the bare leads of both watchdog cables to TB1 on the RS-232 switch panel and the DB9 serial connector to either P1 or P9.
8. Connect one end of the ping cable to the first D20 and the other end to the second D20. This ping cable must be connected to the same serial port number on both units.
9. Use standard RS-232 cables (GE part number 977-0121) to connect the D20 serial communication ports to the serial ports on the RS-232 switch panel. P1 through P8 are connected to the first D20, P9 through P16 are connected to the second D20. Connections from the switch panel to both D20 units should be made in the same order. For example, if P1 is connected to port 3 on the first D20, P9 should also be connected to port 3 on the second D20.
10. Connect field devices to J1 through J8 on the RS-232 switch panel.

RS-232 switch panel operation

The RS-232 switch panel has two sets of indicator LEDs:

- PWR A/PWR B: When lit, power and communications are received from the connected units. Normally, both LEDs are lit.
- CCU A/CCU B: Normally, one LED is lit, indicating which unit is active.

The active/standby switch on the front of the RS-232 switch panel is used to:

- Restore a previously failed unit to active status once it has been repaired.
- Manually force a unit to active status so that routine maintenance can be performed on the other unit.

To manually operate the RS-232 switch panel

1. Pull the active/standby switch straight out to release it from the locked position.
2. Switch it up to make unit A active or down to make unit B active.

The CCU A/CCU B LED indicator indicates which unit has been activated.


Redundancy wiring diagrams

Figure 22 illustrates how to wire the D20MX units and RS-232 switch panels to enable system redundancy:



The D20MX watchdog (control) port, heartbeat (ping) port, and serial port assignments are software configurable. Refer to the *D2x Configuration Guides*.

Figure 22: Redundancy wiring - single RS-232 switch panel



D20MX Processor

Chapter 4: Powering-up and Testing

Once you have made all field wiring and communication connections and have completed the necessary hardware configuration, the next step is to power-up the D20MX and verify that it is functioning properly.

Use this chapter to prepare for and correctly perform the power-up and other tests. This chapter includes:

- What is needed to test: WESMAINT II+ facility, SHELL and SGConfig
- How to power-up the D20MX and conduct the BOOT Test: Power On Self-Test
- How to carry out a redundant system test



Before any of the tests and procedures in this section can be performed, a valid configuration file must be loaded into the D20MX NVRAM.

If you have replaced the main board of the D20MX, then you will need to restore the configuration file so that diagnostic tests can be performed.

If this power-up and test procedure reveals that your D20MX is not functioning properly due to software malfunction, then you need to download code and configuration files.

See the SGConfig online help.

Required for testing

The system components that are required for configuring and testing the D20MX are:

- WESMAINT II+ facility
- SHELL
- SGConfig application

NOTICE

To prevent burning out the main processor board, make two important checks before switching on the D20MX:

- Check that the external power supply input level is correct for the Power Supply fitted to the chassis. See section: "Power supply" on page 22.
- If you have 125 V DC or 110V AC input, then jumpers Z22 and Z23 on the WESTERM D20M+: 517 - 0225 or 517 - 0224 must be jumpered 2 - 3.

Accessing WESMAINT II+ using a terminal

You can use a VT100-compatible terminal or a terminal emulation program to directly access the WESMAINT II+ facility. SGConfig's Terminal Emulator is an example of a suitable terminal emulation program.



NOTE

For further information about using WESMAINT II+ software to perform any of the test procedures in this section, refer to the *WESMAINT II+ User's Guide*.

Terminal Emulation

Microsoft Windows™ HyperTerminal can be used for terminal emulation but it is NOT recommended because code and configuration file download times are considerably increased.



TIP

The program Tera Term for Microsoft Windows™ does not have these limitations and is therefore recommended as a terminal emulation program. It can be downloaded from the Internet.

SHELL

The SHELL is a debugging and diagnostics tool that is accessible as a menu selection in WESMAINT II+, or from a basic login prompt if WESMAINT II+ is not available.

NOTICE

The approved method of using the diagnostic tools of the SHELL is through the front RS232 port.

Power up and test steps

To power up and test the D20MX:

1. "Set up a PC to act as a WESMAINTII+ terminal". See page 57.
2. "Power up the D20MX" on page 57. See page 57.
Result: The D20MX automatically runs the Online Start-up test. See "Automatic on-line start-up test" on page 57.
3. "Test for redundancy". See page 58.
4. "Check that fail-over is functioning correctly". See page 59.
5. "Check that switch-over is functioning correctly". See page 59.
6. "Verify either hardware or software switch-over". See page 60.

Set up a PC to act as a WESMAINTII+ terminal

To set up a PC to act as a WESMAINT II+ terminal.

1. Open the VT100 compatible terminal emulation software you are going to use.
2. Verify (or set) terminal communications settings as follows:

Setting	Value
Data Rate	19200 bps
Data Bits	8
Stop Bits	1
Parity	None
Flow Control	Xon/Xoff (software)
Connector Settings	COM1 or COM2, as required by the computer you are using

Result: The terminal emulator settings are now configured.

Power up the D20MX

To power up the D20MX

1. Check that all field wiring, grounding wires and fuses are in place and secure on your D20 system.
2. Turn the chassis-mounted Power Supply switch to ON.

Result: The unit is powered-up.

3. On start-up, inspect the D20MX LED indicators on the front panel.

Result: The RDY LED is flashing.

Automatic on-line start-up test

The D20MX automatically boots up when the power is switched on. Internal processes perform a series of routines. Self-diagnostic tests are performed followed by the spawning of all the software applications that reside in the unit's memory.

The self-diagnostic tests generate PASS or FAIL messages that can be viewed in your terminal emulator WESMAINT II+ screen. You can also see the results of the application spawning process.

Pass/Fail tests are carried out on the:

- User RAM
- NVRAM
- FLASH memory
- Root process

The self-diagnostics also return measures for:

- SDRAM size
- Bus Speeds
- CPU Core Speed

The NVRAM CRC test verifies that the configuration header is valid. If this fails, then the D20MX starts with a minimal set of applications that allow the system to be restored.

Code and configuration files

If the code and configuration files compiled for your specific system are already downloaded, then you can login straightaway to WESMAINT II+ for powering-up and testing.

If your system-specific code and configuration files are not downloaded, then you need to power-up with the default configuration. You can then login to the SHELL, download your system-specific files and restart the D20MX for testing.

For details, see the SGConfig online help.

Further testing

For further specific testing, log in to WESMAINT II+. See the WESMAINT II+ Users Guide and WESMAINT user guides for specific applications.

Test for redundancy

If you have a D20 redundant system, you must test that:

- CCU A and CCU B are communicating
- Fail-over is functioning correctly.

To check that CCU A and CCU B are communicating once you have powered-up the Primary and Secondary units:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.



Both the PWR A and PWR B LEDs should be illuminated.

2. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the active D20MX.
3. Attach the other end of the cable to the serial communications port of the PC or terminal.
4. Login to WESMAINT II+ through the emulator you are using.
Result: The WESMAINT Main Menu is displayed.
5. Check to see that STNBY appears at the top-left of this WESMAINT screen.
Results: If this text shows, then the Primary and Secondary CCU are communicating.
If this text does not show, then the Primary and Secondary are not communicating.



STNBY appears on the Active CCU WESMAINT Main Menu display approximately one minute after power-up of the two units. Wait for this message to appear before following the next procedure.

Check that fail-over is functioning correctly

To check that fail-over is functioning correctly for the event of hardware failure:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.



Both the PWR A and PWR B LEDs should be illuminated.

2. To simulate hardware failure, switch off the Active D20MX at the main power switch on the front of the unit.

Result: If the RS-232 is functioning correctly, then it will switch over to the Standby unit and the CCU B LED will illuminate and the CCU A LED will go off.

Check that switch-over is functioning correctly

To check that switch-over is functioning correctly for the event of software failure:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.



Both the PWR A and PWR B LEDs should be illuminated.

2. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the D20MX designated as CCU A.
3. Attach the other end of the cable to the serial communications port of the PC or terminal.
4. Login to WESMAINT II+ on CCU A using your terminal emulator.
Result: The WESMAINT Main Menu appears.
5. Select **Main Menu > System Functions** and press **ENTER**.
Result: The WESMAINT Function Menu appears.
6. Select **SWITCH-OVER** on the **Function Menu** and press **ENTER**.
Result: A password prompt appears.
7. Enter your password and press **ENTER**. The default password is *control*.
Result: The CCU Switch-Over display appears.
8. Press **Ctrl-V** to begin switch-over.
Result: A confirmation message appears: *Confirm Yes/No*.
9. Type **Yes** and press **ENTER**.
Result: Fail over occurs

Verify either hardware or software switch-over

To verify either hardware or software switch-over.

1. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the D20MX designated as CCU B, which was originally the Standby unit.
2. Attach the other end of the cable to the serial communications port of the PC or terminal.
3. Login to WESMAINT II+ through the emulator you are using.
Result: The WESMAINT Main Menu is displayed.
4. If you can login to WESMAINT II+, this indicates that CCU B is the Active CCU.
Results: Fail over has occurred.



If the previously Active A CCU powers-up after a fail-over from CCU A to CCU B, then STNBY appears at top left when you login to WESMAINT II+ on CCU B. This can take up to a minute to occur.



If you cannot login to WESMAINT II+ on a CCU, then the unit is most likely powered down. Verify that the RDY LED is flashing and verify that the serial cable is connected correctly.

D20MX Processor

Chapter 5: Configuring the Software

This chapter provides:

- An introduction to the software components used in the D20MX.
- An overview of the software tools you will use.
- How to download image files to the Flash memory on your D20MX module on your system using a serial or network connection.
- A description of the SGConfig™ firmware options
- How to transfer D20/D200 configurations to the D20MX
- How to update D20/D200 configurations to use the D20MX firmware definition

Introduction to the D20MX software

The D20MX main processor board requires three valid files to be loaded:

- An operating system image file, called “vxWorks”, which resides in the file system on Flash memory
- An application image file, called “appl.out”, which resides in the file system on Flash memory
- A configuration file which resides in the NVRAM

Use this section to load the image files of your RTU system.

Image file terms

The following terms are used throughout this chapter of the manual when referring to the image files:

- Collectively the files vxworks and appl.out are to be referred to as “image files”
- vxworks refers to the “operating system image file”
- appl.out refers to the “application image file”

D20MX user accounts

The D20MX supports the following types of user accounts:

- Remote and local user accounts
- Factory default user account
- System default user account

Remote and local user accounts

The D20MX supports remote and local user accounts. Use remote user accounts whenever possible to increase the level of security and to decrease user administration effort. To implement remote user accounts, the D20MX uses Remote Authentication Dial-In User Service (RADIUS) with CHAP, EAP-TTLS and PEAP authentication methods. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure the D20MX to use RADIUS.

When RADIUS is used, your RADIUS server provides a role ID to the D20MX. The role ID defines which commands and displays the user is allowed to access while logged in to the D20MX. To allow your RADIUS server to provide a role ID, configure your RADIUS server to use the GE vendor profile that is common to many Multilin products. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure your RADIUS server and the D20MX with the GE vendor profile. Also refer to Appendix A, *Default Role-Based Access Control Model* for the default role based access control model provided with the D20MX default configurations.

In the event all configured RADIUS servers are down or if RADIUS is not configured, the D20MX authenticates the user against the local configuration and password file. Local users are created with a default password of **changeme**. Use the **passwd** command from the D20MX SHELL prompt to change the default password to a strong password as soon as possible after downloading the configuration. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure local user accounts and change the password of a user.

Factory default user account

The factory default configurations for the D20MX come with one default user account with:

- username: **admin**
- password: **changeme**

Replace this account or change the password for this account as soon as possible. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to modify user accounts and how to change the password of a user.

System default user account

The D20MX configuration can be defaulted by pressing CTRL-F on a terminal connected over the front RS232 port during startup. In addition, if the D20MX detects a corrupt configuration on startup, it generates a system default configuration. The system default configuration comes with one user account:

- username: **recover**
- password: **system**

Login with this username and synchronize a configuration to the D20MX over the front RS232 port.



NOTE

The D20MX can only be accessed over the front RS232 port with the system default configuration.

If you synchronize a configuration with any of the following errors:

- There are no usernames configured in the B014 User table,
- The B014 User table is disabled, or
- The B014 application definition does not match the firmware version,

then the applications do not start and you only have serial access in debug mode.

Login with the system default username over the front RS232 port and synchronize a correct configuration.

Download image files to the D20MX

When to download

Instances where you may need to download an operating system or application image file to your D20MX:

- When a new version of the operating system or application image has been released.
- If the D20MX has performed self-diagnostics and determined that the application image file is either missing or corrupted.
- After maintenance or replacement work that has deleted the application file.

Prerequisites for image download

The following items must be available before an application or operating system image file can be loaded into a D20MX over a serial or network link:

- Windows PC with SGConfig version 7.2 and higher software.
- The application firmware file, preferably located on a local hard drive.
This file will be named: appl.out.
- The operating system image file, preferably located on a local hard drive.
This file will be named: vxWorks.
- The D20MX module must be installed into a D20 chassis, ready to power-up.

Prerequisite for image download over a serial link

The following item must be available before an application and operating system image file can be loaded into a D20MX over a serial link:

- A NULL modem cable (GE Energy part number 977-0529) connecting the RS-232 connector on the front panel of the D20MX to the serial communications port of a PC or terminal.

Prerequisite for image download over a network link

The following items must be available before an application and operating system image file can be loaded into a D20MX over the network:

- An Ethernet switch and appropriate Ethernet patch cables to connect your PC's Network Adapter and the D20MX's Ethernet port 1 to the switch.
- The D20MX contains a configuration file with LAN enabled and an IP address that matches the one configured in SGConfig.
- The PC's Network Adapter is configured with an IP address on the same network as the IP address of the D20MX.

Download software over a serial connection

To download software to the D20MX:

1. Set up Tera Term on a PC. See section: "Set up Tera Term on a PC" on page 64.
2. Download application image file to the D20MX over a serial connection. See section: "Download image files to the D20MX over a serial link" on page 65.

This comprises:

- Application files
- Operating system files

Set up Tera Term on a PC

To set up the Tera Term on a PC:

1. Connect a NULL modem cable (GE Energy part number 977-0529) from the RS-232 connector on the front panel of the D20MX to the serial communications port of the PC or terminal.
2. Start SGConfig.
Result: The Welcome to SGConfig screen appears.
3. Open a project containing a D20MX device.
Result: The project's Main Page appears.
4. Click on a D20MX device.
Result: The ribbon changes to include the Communications group.
5. Click **Configure** ribbon group > **Communications** > **Connect** drop-down list > **Tera Term**.
Result: Tera Term: New connection dialog appears
6. Click **Serial** and select the communications port on your PC from the **Port** drop-down list.
7. Click **OK**.
Result: Tera Term: New connection dialog closes
Result: The Tera Term VT window appears
8. Select **Setup > Serial port...**
Result: Tera Term: Serial port setup dialog appears
9. Verify (or set) terminal communication settings as follows:

Setting	Value
Port:	COM1 or COM2, or as required by the computer you are using.
Baud Rate	19200 bps
Data	8 bit
Parity	none
Stop	1 bit
Flow Control	Xon/Xoff
Transmit delay	0 msec/char; 0 msec/line

10. Click **OK**.
Result: The Tera Term settings are now configured.

Download image files to the D20MX over a serial link

To download application and operating system image files to a D20MX module:

1. Restart the D20MX.
Result: The startup messages appear.
2. When the message "Press Ctrl-E to enter debug mode..." appears, press **Ctrl-E** within 5 seconds.
Result: The login dialog appears.
3. Log in:
 - For **User**: type a username that has Maintenance or Read/Write Access and press **Enter**,
 - For **Password**: type the password and press **Enter**.

Result: The D20M> prompt appears.

4. Optional: Speed-up communications to shorten download time.
Type **Baud 115200** and press **Enter**.

Note: Select 57600 or 38400 if communications errors have occurred previously. Such errors can occur due to the presence of ambient EMI, a long cable length, a PC with communication limitations due to CPU speed or when using some serial to USB adapters.

Result: The D20MX is now communicating at 115,200 baud.

- 4.1. Select **Setup > Serial port...**

Result: Tera Term: Serial port setup dialog appears.

- 4.2. Select **115,200** from the **Baud Rate** drop-down list.

- 4.3. Click **OK**.

Result: Tera Term main window appears and is communicating at 115,200 baud.

5. Download the application image file:

- 5.1. Press **Enter** to verify that communication is active.

Result: The D20M> prompt appears if the connection is active.

- 5.2. Type **rz** and press **Enter** to put the D20MX into the state where it is ready to receive the downloadable code file

- 5.3. Click **File > Transfer > ZMODEM > Send** from menu bar

Result: A dialog box opens, prompting you to locate the appl.out file that you wish to download.

- 5.4. Select the correct file, and click Open to start the transfer

Do not press any keys on keyboard and do not move the Tera Term window during download.

Result: The file transfer may take from less than 10 to over 30 minutes, depending on communication speed selected.
When complete, the D20M> prompt appears.

6. Download the operating system image file

- 6.1. Press **Enter** to verify that communication is active.

Result: The D20M> prompt will return if connection is active

- 6.2. Type **rz** and press **Enter** to put the D20MX into the state where it is ready to receive the downloadable code file.

- 6.3. Click **File > Transfer > Send** from menu bar.

Result: A dialog box appears, prompting you to locate the vxWorks file that you wish to download.



NOTE

- 6.4. Select the correct file, and click **Open** to start the transfer



Do not press any keys on keyboard and do not move the Tera Term window during download.

Result: The file transfer may take from less than 10 to over 30 minutes, depending on communication speed selected.
When complete, the D20M> prompt appears.

7. Type **cf** to copy the image files to flash.
Result: The copy may take a few minutes to complete. When complete, the D20M> prompt appears.
8. Type **el /r** to ensure that log is clear.
9. Type **boot** to restart device.
Result: The image file load is completed.
The flash memory of the D20MX now has the new application and operating system image file loaded.

Configuration File Download

You can use standard SGConfig procedures to download a configuration file over the serial port.

Download image files over a network connection

Procedure

To download application and operating system image files to the D20MX over a network connection:



In the event that you have selected dialog checkbox “Do not show this message again”, some of the following steps do not appear. Accordingly, ignore the affected steps.

1. Connect Ethernet port 1 of the D20MX to the Ethernet switch using the appropriate Ethernet patch cable.
2. Connect the PC's network adapter to the Ethernet switch using the appropriate Ethernet patch cable.
3. Start SGConfig.
Result: The Welcome to SGConfig screen appears.
4. Open a project containing the target D20MX device.
Result: The project's Main Page appears.
5. Click on the D20MX device.
Result: The Communications group appears in the ribbon.
6. Click **Configure** ribbon group > **Communications** > **Options**.
Result: D2x Device Communication Options dialog appears
7. Click **Interface** tab > Connection Type > **iSCS LAN** and select the Preferred LAN you wish to use, either **LAN A** or **LAN B**. This will most likely be **LAN A**.
8. Click **OK**.
Result: D2x Device Communication Options dialog closes.
9. Click **Edit** ribbon group > **Properties**.
Result: A Dialog appears, prompting you to make a backup copy.
10. Click **Yes** or **No** depending on whether you want to make an internal backup copy.
Result: If you click **Yes**, a dialog appears indicating that the device is being backed up. Finally, a dialog appears indicating that the device has been backed up.

11. Click **OK**.

Result: The D20 Device Wizard appears

12. Click **Next**.

Result: The Project LAN properties appear.

13. Click **Next**.

Result: The hardware and other properties appear for the device.

14. Click **Processor** tab > **Code Image** sub-tab.

15. Click the button with the ellipsis (...).

Result: The Select Flash image file dialog appears.

16. Navigate to the folder containing the appl.out file and vxWorks file.

17. Select the **appl.out** file and click **Open**.

Result: The full pathname of the appl.out file appears in the Flash Image File box.

Note: To transfer the operating system image, simply ensure that a vxWorks file exists in the same folder as the selected appl.out file. SGConfig automatically transfers both files to the D20MX even though you only selected the appl.out file.

18. Click **Next**.

19. Click **Finish**.

Result: The project's Main Page appears with the D20MX device selected.

20. Click the ribbon **Configure** group > **Configuration** > **Generate**.

21. Confirm that there are zero errors in the Device Log.

22. Click the ribbon **Communications** group > **Firmware transfer**.

Result: Warning message appears and confirmation to continue is requested.

23. Acknowledge the warning and click **Yes** to continue or **No** to abort the operation.

Result: If Yes is selected, then refer to the following table. If No is selected, the operation is aborted.

Possible Result if Yes is Selected	When to expect this result	Go to step
Select Target IP Address dialog appears	If the D20MX is configured for device redundancy.	24
Login dialog appears	If the D20MX is not configured for device redundancy.	26

24. Choose one of the following options:

- If the default standby IP address is not the correct one, click the **Standby IP address** checkbox and in the associated IP address field, enter the IP address of the standby unit.

Tip: Click **Help** for information on how to determine the Standby IP address.

- Click the **Active IP** address checkbox.

25. Click **OK**.

Result: A login dialog appears.

26. Enter a **User Name** that has Maintenance or Read/Write access. Enter the associated **Password**.

Result: The firmware transfer takes place. A dialog indicating the transfer and reboot is taking place is presented. The unit is rebooted once the transfer finishes. Once the reboot completes, the dialog disappears. The whole operation can take up to 8 minutes.

The flash memory of the D20MX now has the new application and operating system image file loaded.

27. If the D20MX was configured for device redundancy, you may switch over the D20MX and repeat the above steps for the other unit.

Configuration file download

You can use standard SGConfig procedures to download a configuration file over the network.

Firmware integrity

Version 1.10 of the D20MX firmware introduced a Firmware Integrity checking mechanism. This mechanism consists of a Primary and Secondary storage system, internal to the D20MX, for the firmware files and an MD5 checksum on the individual firmware files.

Version 1.20 of the D20MX firmware adds the two D20M Shell commands: **commit** and **revert**. These commands copy the firmware files from the Primary storage to the Secondary (commit), or from the Secondary to the Primary (revert).

The D20MX determines which set of files (Primary or Secondary storage) to use when starting up by:

1. Testing the integrity of the D20MX firmware files in the Primary storage.
2. If the integrity check of the Primary storage files is valid, the D20MX starts up with the Primary storage files.
3. If the integrity check of the Primary storage files fails, the D20MX tests the integrity of the firmware files in the Secondary.
4. If the integrity of the Secondary storage files is valid, the D20MX starts up with Secondary storage files.
5. If the integrity of the Secondary storage files fails, the D20MX defaults to the Boot ROM command prompt.

Committing new firmware

After new firmware has been downloaded (either via serial or network connection), and the D20MX has restarted and is operating correctly, the firmware must be “committed” to the secondary storage.

NOTICE

Once the firmware has been committed, it cannot be reverted; see Section: Reverting old firmware.

To commit new firmware:

1. Login as a user that has Maintenance or Read/Write access privileges.
2. Enter the D20M Shell.
3. Enter the **commit** command.

Result: A prompt appears to confirm copying the firmware from Primary to Secondary.

4. Enter **yes** to confirm the copy operation. If anything else is entered, the command is canceled.

Result: The firmware copy operation begins. Both 'vxworks' and 'appl.out' are copied.

This operation takes approximately 3 minutes.

NOTICE

DO NOT shut off the power to the D20MX while the copy operation is in progress. If power to the D20MX is disrupted, during the copy operation, the firmware will likely be corrupted.

Reverting old firmware

A previously committed version of the firmware may be recovered from secondary storage.

This feature is intended to be used when the primary version of the firmware has become corrupt. Reverting the firmware copies the firmware from secondary storage into the primary storage.

If, after downloading a new version of the firmware, an issue is identified in the new firmware, the previous version may be recovered. This is only possible if the new firmware has not been committed; see Section: Committing new firmware.

To commit new firmware:

1. Login as a user that has Maintenance or Read/Write access privileges.
2. Enter the D20M Shell.
3. Enter the **revert** command

Result: A prompt appears to confirm copying the firmware from Secondary to Primary.

4. Enter **yes** to confirm the copy operation. If anything else is entered, the command is canceled.

Result: The firmware copy operation begins. Both 'vxworks' and 'appl.out' are copied.

This operation takes approximately 3 minutes.

NOTICE

DO NOT shut off the power to the D20MX while the copy operation is in progress. If power to the D20MX is disrupted, during the copy operation, the firmware will likely be corrupted.

5. Once the copy operation has completed, enter the **boot** command to restart the D20MX with the reverted firmware.

Migrate D20MX application definitions to SGConfig

Use this information to migrate the D20MX application definitions to SGConfig. This step only needs to be performed once on a configuration computer.

Prerequisites

Before you can migrate the D20MX application definitions to SGConfig, the following components must be present:

- SGConfig 7.2 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075 V120) installed in a CD/DVD drive of the configuration computer.

Procedure

To migrate the D20MX application definitions to SGConfig:



Ignore any steps that refer to dialogs where you selected "Do not show this message again".

1. Start SGConfig.
Result: The Welcome to SGConfig screen appears.
2. Click the **GE** button > **Migration Wizard**.
Result: The Welcome to the Migration Wizard screen appears.
3. Click **Next**.
Result: The Select Task screen appears.
4. Select **Import application definitions** and click **Next**.
Result: The Import application definitions screen appears.

5. Click the **Retrieve from archive** button.
Result: The Choose file dialog appears.
6. Navigate to the folder **Configuration Files\ApplicationDefinitions** on the D20MX Documentation CD, and select the zip file there. Then, click **OK**.
Result: The Import application definition screen re-appears. The Available Applications list contains many applications.
7. Click **Select All** and then **Next**.
Result: The Importing Application Definitions progress dialog appears momentarily. The migration may take a few minutes.
Result: The Task completed dialog appears.
8. Click **Next** and **Finish**.

Transfer D20/D200 configurations to the D20MX

Use this information to transfer existing D20 and D200 device configurations to the D20MX.



The word “transfer” is used within the context of this guide to mean that the device configuration files are moved and modified, in order to work properly on a D20 with a D20MX processor.

If you are transferring a D20 device configuration, follow the steps in section: “Transferring a D20 configuration to the D20MX” on page 70.

If you are transferring a D200 device configuration, follow the steps in the following sections:

- Section: “Transferring a D200 configuration to the D20MX” on page 77
- Section: “Transferring a D20 configuration to the D20MX” on page 70

Transferring a D20 configuration to the D20MX

Prerequisites

Before you can transfer a D20 device configuration, the following components must be present:


- SGConfig 7.2 or higher installed on the configuration computer.
- The D20MX application definitions have been migrated to the configuration computer using the instructions in Section: *Migrate D20MX application definitions to SGConfig*.
- The D20MX Documentation CD (part number 588-0075 V120) installed in a CD/DVD drive of the configuration computer.
- D20 Configuration has been migrated to SGConfig with the Migration Wizard (Refer to the Migration Wizard screencast).
- To save time, you may upgrade the firmware definition of your D20 or D200 Configuration to SAN0001 or SAN0002 in ConfigPro™. If you choose to take this option, follow the instructions provided in Section: “Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro” on page 78, before migrating the D20 configuration to SGConfig.
- A NULL modem cable (GE part number 977-0529) connecting the RS-232 connector on the front panel of the D20MX to the serial communications port of the configuration computer.

Procedure**NOTE**

To transfer a D20 or D200 device configuration to the D20MX:

In the event that you have selected dialog checkbox “Do not show this message again”, some of the following steps do not appear. Accordingly, ignore the affected steps.

1. Start SGConfig.
Result: The Welcome to SGConfig screen appears.
2. Choose the D20MX Factory Default Configuration file, SAG0001-02.7zip or SAG0002-02.7zip, based on the following criteria:
 - If transferring a configuration containing B009 versions greater than 310 and B021 versions greater than 912 use the file SAG0001-02.7zip
 - If transferring a configuration containing B009 versions less than or equal to 310 and B021 versions less than or equal to 912, use the file SAG0002-02.7zip.
3. If the SAG0001 or SAG0002 default configuration has already been imported, go to step 4 to open the default configuration. Otherwise perform these steps:
 - 3.1. Click **GE** button > **Archive** > **Project** > **Restore**.
Result: The Restore Project Details window appears.
 - 3.2. Click
Result: The Choose a File window appears.
 - 3.3. Navigate to the DVD/CD drive > Configuration Files > SGConfig.
Result: The two files SAG0001-02.zip and SAG0002-02.zip appear in the dialog.
 - 3.4. Select the appropriate file based on your decision in step 2.
 - 3.5. Click **OK**.
Result: On completion a pop-up message appears (e.g. Project 'SAG0001' has been restored).
 - 3.6. Click **OK**.
4. Open the D20MX Factory Default Configuration SAG0001 or SAG0002: click **GE** > **Recent Projects** > select **SAG0001-02** or **SAG0002-02**.
5. Copy the firmware definition from the factory default configuration to the project containing the D20 configuration (if you had opted to upgrade the firmware in ConfigPro, then this step is not necessary):
 - 5.1. Click anywhere on the main page of the project to deselect the device.
 - 5.2. Click the ribbon **Configure** group > **Miscellaneous** > **Firmware Library**.
Result: The Firmware Library window appears with the firmware definition selected.
 - 5.3. Select **SAN0001/002** or **SAN0002/002** based on the decision taken in step 2.
 - 5.4. Click **Copy**.
Result: The Firmware Information window appears.
 - 5.5. Set the **Project Name** in the Copy To region to the project containing the D20 configuration.
 - 5.6. Click **OK**.
Result: The Firmware Information window closes.
 - 5.7. Click **Close**.
Result: The Firmware Library window closes.
6. Export the RADIUS roles from the default configuration:
 - 6.1. Double-click the D20 device named FAC_DEF.
Result: The Application List popup appears.
 - 6.2. Double-click the WESMAINT II+ application.
Result: The WESMAINT II+ table icon set appears.

- 6.3. Right-click the RADIUS Role Table icon and select **Export**
Result: The Export Options dialog appears.
- 6.4. Use the default settings for System Point Fields and click on the button containing an ellipsis (...) under the Place export files in area.
Result: The Choose a folder dialog appears.
- 6.5. Browse to a folder (e.g. your Desktop) and click **OK, OK, Cancel**, and **Close**.
Result: The main page of the project appears.
7. Export the IP Redundancy Monitor point descriptors from the default configuration:
 - 7.1. Double-click the D20 device named FAC_DEF
Result: The Application List popup appears.
 - 7.2. Double-click the System Point Database application.
Result: The System Point Database Properties dialog appears.
 - 7.3. Select IP Redundancy Monitor and click **Descriptors**.
Result: The Point Descriptors dialog appears.
 - 7.4. Click on the Export button. 
Result: The Export Point Descriptors dialog appears.
 - 7.5. Use the default settings for the **Select Range of Points to Export** and click **OK**.
Result: The Browse For Folder dialog appears.
 - 7.6. Browse to a folder and click **OK, OK, Cancel** and **Close**.
Result: The main page of the project appears.
8. Close the D20MX Factory Default Configuration (i.e. SAG0001 or SAG0002):
 - 8.1. Click **GE > Close Project**.
Result: The Close Project window appears.
 - 8.2. Select: **SAG0001-02** or **SAG0002-02**.
 - 8.3. Click **OK**.
9. Open the SGConfig project containing the D20 device.:
 - 9.1. Click the **GE** button.
 - 9.2. Click the required SGConfig project in the **Recent Projects** list or select the **Open Project** menu item.
10. Generate a report of the applications in the original D20 device configuration and determine the unused applications.
 - 10.1. Click the Project tab of the original D20 device configuration.
 - 10.2. Click the D20 device.
 - 10.3. Right click the D20 device > **Miscellaneous > Reports**.
Result: The Select Reports dialog appears.
 - 10.4. Click **Application List** and **OK**
Result: An new tab named Reports opens and contains the Application List report for the original D20 device.
 - 10.5. Compare the Application List report with Table 2 on page 16.
With the exception of IP Redundancy Monitor (B152-1), note the applications that appear in Table 2 but not in the report. You may want to print Table 2 and mark these applications. These applications are referred to as “unused” applications in the steps to follow.
 - 10.6. Click the **x** button on the **Reports** tab.
Result: The Project tab of the original D20 device configuration reappears.
11. Make a backup copy of the original D20 device configuration:
 - 11.1. Click the **Project** tab of the original D20 device configuration.

- 11.2. Click the D20 device.
- 11.3. Click the ribbon **Configure** group > **Edit** > **Copy**.
- 11.4. Click a blank area on the page onto which the copy is to be placed.
- 11.5. Click the ribbon **Configure** group > **Edit** > **Paste**.
 Result: The Copying device window appears.
 Result: Once completed a new device named COPY_OF_<original device name> or <original device name>_COPY appears.
12. Select a D20MX processor from the D20 Device Wizard:
 - 12.1. Click the **Project** tab of the original D20 device configuration.
 - 12.2. Click the D20 device.
 - 12.3. Click the ribbon **Configure** group > **Edit** > **Properties**. Result: A Warning prompts you to save an internal backup copy.
 - 12.4. Click **Yes** to create a backup, or **No** to not create a backup.
 Result: The D20 Device Wizard Basic Settings window appears.
 - 12.5. Click **Next** until the Processor tab appears.
 - 12.6. Click the **Processor** tab > **General** sub-tab.
 - 12.7. From the Part Number field, click **Select**.
 Result: The Select a Processor Card window appears.
 - 12.8. Select one of the three D20MX processor type part numbers (526-3001, 526-3003 or 526-3005).
 - 12.9. Click **OK**, **Firmware** tab, and **Select**.
 - 12.10. Select either **SAN0001 / 002** or **SAN0002 / 002** as per the decision taken in step 2. If you had opted to upgrade the firmware in ConfigPro, then this step is not necessary.
 - 12.11. Click **OK**.
 - 12.12. Click **Next** and **Finish**.
 Result: The D20 Device Wizard closes.
Note: This process can take awhile. Most of the warnings that occur at the end of this process will disappear after the completion of Step 18.
13. Ensure the BOOTP client is disabled:
 - 13.1. Click the **Project** tab of the original D20 device configuration.
 - 13.2. Click the D20 device.
 - 13.3. Click the ribbon **Edit** group > **Properties**.
 Result: A Warning prompts you to save an internal backup copy.
 - 13.4. Click **Yes** to create a backup, or **No** to not create a backup.
 Result: The D20 Device Wizard appears.
 - 13.5. Click **Next** until the Processor tab appears.
 - 13.6. Click the **LAN Settings** tab > **General** sub-tab.
 - 13.7. From the BOOTP Settings frame, ensure **Not Used** is checked.
 - 13.8. Click **Next** and **Finish**.
 Result: The D20 Device Wizard closes.
14. Disable unused applications:
 - 14.1. Click the **Project** tab of the original D20 device configuration.
 - 14.2. Double-click the D20 device.
 Result: The Application List popup appears.

- 14.3. Press the **Ctrl** key and click on the applications you noted in step 10 as unused applications.
Result: The rows showing unused applications are highlighted.
- 14.4. Click on **Disable Application(s)**.
Result: A warning dialog appears.
- 14.5. Click **Yes**.
Result: The warning dialog and the Application list popup disappear.
15. Import the RADIUS roles from the D20MX default configuration into the D20 device:
 - 15.1. Double-click the D20 device.
Result: The Application List popup appears.
 - 15.2. Double-click the WESMAINT II+ application.
Result: The WESMAINT II+ table icon set appears.
 - 15.3. Right-click the RADIUS Role Table icon and select **Import**.
Result: The Select source directory dialog appears.
 - 15.4. Browse to the folder containing the exported RADIUS Role Table, select the file named **B014RADR.CSV**, and click **Open**.
Result: The WESMAINT II+ table icon set re-appears.
 - 15.5. Double-click the RADIUS Role Table icon.
Result: The RADIUS Role Table editor appears.
 - 15.6. Compare the first column of the Access Flags sub-table (RADIUS Role Table > Application Control) to the following figure to confirm that the import was successful:

Role	Role ID	Role Name
1	0	Observer
2	1	Engineer
3	2	Administrator
4	3	Operator

Appl	Application Number	Modify-0	Modify-1	Modify-2
1	14	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
2	32045	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
3	36	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
4	32021	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
5	162	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
6	32013	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
7	59	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
8	68	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
9	32071	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
10	27	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
11	78	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
12	101	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
13	105	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
14	199	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
15	32085	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable	<input type="checkbox"/> Disable
16	0	<input type="checkbox"/> Enable	<input type="checkbox"/> Enable	<input type="checkbox"/> Enable

Numeric ID of the application (eg. enter '14' for WESMAINT, application A014).

1/64

OK Cancel Help

- 15.7. Click **OK, OK and Close**.
Result: The WESMAINT II+ table editor closes.
16. Import the IP Redundancy Monitor point descriptors:
 - 16.1. Click the **Project** tab of the original D20 device configuration.
 - 16.2. Double-click the D20 device.
Result: The Application List popup appears.
 - 16.3. Double-click the System Point Database application.
Result: The System Point Database Properties dialog appears.
 - 16.4. Select IP Redundancy Monitor and click **Descriptors**.
Result: The Point Descriptors dialog appears.

- 16.5. Click on the **Import** button.

Result: The Import Point Descriptors dialog appears.


- 16.6. Use the default settings for the **Select Range of Points to Import** and click **OK**.

Result: The Browse For Folder dialog appears.

- 16.7. Browse for the folder containing the exported IP Redundancy Monitor point descriptions and click **OK**.

Result: The Point Descriptors dialog appears.

- 16.8. Confirm the point descriptors are as shown in the following figure.



- 16.9. Click **OK**, **OK** and **Close**.

Result: The main project window appears.

17. Change the baud rate of COM0 to 19.2K:

- 17.1. Click the **Project** tab of the original D20 device configuration.

- 17.2. Double-click the D20 device.

Result: The Application List popup appears.

- 17.3. Double-click the WESMAINT II+ application.

Result: The WESMAINT II+ table icon set appears.

- 17.4. Double-click the Port Configuration table icon.

Result: The Port Configuration table editor appears.

- 17.5. Change the Baud Rate of COM0 to 19.2k.

Result: The WESMAINT II+ table editor closes.

- 17.6. Click **OK** and **Close**.

Result: The main project window appears

18. Optionally, update the RADIUS and SYSLOG settings in B014-1N (WESMAINT II+):

- 18.1. Click the **Project** tab of the original D20 device configuration.

- 18.2. Double-click the D20 device.

Result: The Application List popup appears.

- 18.3. Double-click the WESMAINT II+ application.

Result: The WESMAINT II+ table icon set appears.

- 18.4. Update the new tables: Remote RADIUS Servers Table, Remote Syslog Servers Table, TLS Auth Info Table, TLS CA Info Table, First PEM File Table, Second PEM File Table and Login Warning Banner Table, referring to the B014-1NCG WESMAINT II+ configuration guide.
19. Generate the iSCS Configuration for the Project:
 - 19.1. Click the **Project** tab of the original D20 device configuration.
 - 19.2. Click: the D20 device.
 - 19.3. Click the ribbon **Configure** group > **iSCS** > **Generate**.
 - 19.4. Confirm that there are zero errors in the Device Log; any Warnings are acceptable.
20. Review warnings:
 - 20.1. Click the **Project** tab of the original D20 device configuration.
 - 20.2. Click the D20 device.
 - 20.3. Click the ribbon **Configure** group > **Draw** > select **Output Window**.
Result: The Device Log window appears.
 - 20.4. Review all warnings and make corrections as needed, reviewing the backup copy to retrieve values that may have been replaced with default values during the transfer.
21. Transfer the new configuration to the D20MX:
 - 21.1. Click the **Project** tab of the original D20 device configuration
 - 21.2. Click: the D20 device.
 - 21.3. Click the ribbon **Configure** group > **Communications** > **Options**.
Result: The Device Communication Options window appears.
 - 21.4. Click **Interface** tab > **Connection Type**.
 - 21.5. Select **Direct Serial** and change the **Communications Port** to the serial port that is connected to the D20MX.
Result: The Communications Options window shows that Connection Type is set to Direct Serial and the Communications Port is set to the serial port connected to the D20MX.
 - 21.6. Click the **Port Settings** tab and set the **Baud Rate** to 19200, and select the **Software Transmit** and **Software Receive** check-boxes. Then click **OK**.
Result: The D2x Device Communications Options dialog closes.
 - 21.7. Physically connect the PC's serial port using the RS232 NULL modem cable to either the front serial port of the:
 - **Standby** D20MX, if the D20MX is configured for device redundancy, or
 - **Standalone** D20MX, if the D20MX is configured for standalone operation.
 - 21.8. Click the **Configure** ribbon group > **Communications** group > **Connect**.
Result: The Terminal Emulator window opens.
 - 21.9. Login to the D20MX using the username **admin** and password **changeme**.
Result: The D20M> prompt appears.
 - 21.10. Click the **Configure** ribbon group > **Actions** > **Sync To**.
Result: The Downloading Configuration File dialog appears showing the progress of the download. At the conclusion, a Confirm dialog appears with three buttons: Boot, Verify and Exit.
 - 21.11. Click **Boot**.
Result: The D20MX reboots with the new configuration.



All users that existed in the transferred D20/D200 configuration now have the default password: changeme. Change these passwords using the **passwd** command in the D20MX Shell. Refer to the WESMAINT II+ for D20MX Configuration Guide B014- 0NCG for details of this command.



If the D20MX was configured for device redundancy, once the sync to operation is complete, the standby unit reboots and comes up again as standby with the new configuration. If desired, switch over and synchronize the new configuration to the other unit through the “Switch Over” and “Database Sync” functions available in the WESMAINT System Functions menu. Refer to the WESMAINT II+ for D20MX User’s Guide B014-0NUG for details on these functions.

Transferring a D200 configuration to the D20MX

Prerequisites

Before you can transfer a D200 device configuration, the following components must be present:

- SGConfig 7.2 or higher installed on the configuration computer
- D200 Configuration has been migrated to SGConfig with the Migration Wizard (Refer to the Migration Wizard screencast).

Procedure

NOTICE

Migrating a multi-processor D200 will only transfer the application configurations on the first processor.

This is manually resolved by moving applications from other processors to the first processor using the SGConfig device editing functions BEFORE converting the device to a D20 in the instructions below.

Single and multi-processor D200 devices must first be changed into D20 devices before the D20MX processor card option can be selected. To change a D200 device into a D20 device perform the following steps:

1. Start SGConfig.
Result: The Welcome to SGConfig screen appears.
2. Open a project containing the D200 device you want to transfer to a D20MX:
 - 2.1. Click the **GE** button.
 - 2.2. Click the required SGConfig project in the **Recent Projects** list or select the **Open Project** menu item.
3. Make a backup copy of the original D200 device configuration:
 - 3.1. Click the **Project** tab of the original D200 device configuration.
 - 3.2. Click the D200 device.
 - 3.3. Click the ribbon **Configure** group > **Edit** > **Copy**.
 - 3.4. Click a blank area on the page onto which the copy is to be placed.
 - 3.5. Click the ribbon **Configure** group > **Edit** > **Paste**.
Result: The Copying device window appears
Result: Once completed a new device named COPY_OF_<original device name> or <original device name>_COPY appears.
4. Select the D200 device that needs to be changed to D20 and click the ribbon **Configure** group > **Configuration** > **Change Type**.
Result: The Change Device window appears.
5. Select type **D20** and click **OK**.

6. Follow the steps in section: Transferring a D20 configuration to the D20MX.

Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro

Use this information to update the firmware definition of an existing D20 and D200 device configuration to the D20MX firmware definition. The result is a device archive that you can migrate into SGConfig for the purpose of transferring the D20/D200 configuration to the D20MX. The remaining steps of the transfer are described in "Transfer D20/D200 configurations to the D20MX" on page 70.

If you are updating a D20 device configuration, follow the steps in section: Updating a D20 configuration to use the D20MX.

If you are transferring a D200 device configuration, follow the steps in the following sections:

- "Updating a D200 configuration to use the D20MX firmware definition with ConfigPro" on page 81
- "Updating a D20 configuration to use the D20MX firmware definition with ConfigPro" on page 78

Updating a D20 configuration to use the D20MX firmware definition with ConfigPro


Prerequisites

Before you can update the firmware definition of a D20 device configuration, the following components must be present:

- ConfigPro 5.03 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075 V120) installed in a CD/DVD drive of the configuration computer.

Procedure

To update a D20 or D200 device configuration to the D20MX:

1. Press the Windows Key  and **E** at the same time.
Result: The Windows Explorer window appears.
2. Navigate to a folder to which you have write permissions.
Result: The content of the folder is displayed.
3. Click the **New folder** button in Windows Explorer
Result: A new folder is created with the name "New folder" and the cursor is positioned to allow renaming of the folder.
4. Rename the folder to **D20MXV1.20**.
Result: The folder is renamed to D20MXV1.20.
5. Insert the D20MX Documentation CD in to the computer's DVD/CD drive.
Result: The Documentation CD home page appears in your default Web Browser. If this doesn't happen, navigate to the CD in Windows Explorer, and double click the **readme.html** file on the root of the CD.
6. Under the **D20MX Factory Default Configuration Files** section, click on the link named ConfigPro.
Result: The Factory Default Configuration Files folder is displayed.

7. Using Windows Explorer, copy/paste the files as shown in the following table. To copy a file, select it and press **Ctrl-C**. To paste a file, click on the Windows Explorer window showing the new D20MXV1.20 folder and press **Ctrl-V**.

Navigate to folder on D20MX Documentation CD	Copy/Paste the following files to the new folder D20MXV1.20
10730-02.zip	10730-02.zip
10731-02.zip	10731-02.zip

Result: Windows Explorer window showing the new D20MXV1.20 folder is displaying the files shown in the above table.

8. Start Config Pro 5.03 or higher.
Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
9. Choose the D20MX Factory Default Configuration file, 10730-02.zip or 10731-02.zip, based on the following criteria:
- If transferring a configuration containing B009 versions greater than 310 and B021 versions greater than 912 use the file 10730-02.zip
 - If transferring a configuration containing B009 versions less than or equal to 310 and B021 versions less than or equal to 912, use the file 10731-02.zip.
10. If the 10730-01 or 10731-01 default configuration has already been imported, go to step 18. Otherwise, select from the menu bar **Project > Archive Project > Restore**.
Result: The Restore Project from ZIP File dialog appears
11. Under the Select Source Project ZIP File area, click the **document** icon.
Result: The Select a Project ZIP file to Restore dialog appears.
12. Navigate to the new D20MXV1.20 folder.
Result: The two files 10730-02.zip and 10731-02.zip appear in the dialog.
13. Select the appropriate file based on your decision made in the second step and click the **Select** button.
Result: The Restore Project from ZIP File dialog appears with the selected file showing under the Select Source Project ZIP File area.
14. Under the "Restore To" area, click the **folder** icon.
Result: The Select the Destination Project Directory dialog appears.
15. Navigate to your ConfigPro project folder on a hard drive of the configuration computer. The project folder is typically named C:\WESDATA.
Result: The contents of the project folder are displayed, and the file named *WPL400.DB* is selected.
16. Click the **Select** button.
Result: The Restore Project from ZIP File dialog reappears with the Project Directory set to the folder you selected in the previous step.
17. Change the Project Name if desired and click **OK**.
Result: The main window of ConfigPro appears with the tree view of the project directory on the left. The new D20MX factory default project appears in the tree view.
18. Double-click on the D20MX factory default project.
Result: The Main Page of the D20MX factory default project appears with the FAC_DEF device placed on the page.
19. Double-click the FAC_DEF device.
Result: The Missing Applications! dialog appears.
20. Click the **Install** button.
Result: The Select the Source Application Definition Directory dialog appears.

21. Navigate to the DVD/CD drive > **DEFNS** > **APPLDEF**.
Result: The contents of the APPLDEF folder is displayed with the file *DAL100.DB* selected.
22. Click **Select**.
Result: Messages are displayed about the application definitions being extracted to the configuration computer, and finally the Data Collection Applications of the FAC_DEF device appear.
23. Close the device configuration by clicking on the **door** icon.
Result: The Main Page of the D20MX factory default project appears with the FAC_DEF device appearing on the page.
24. Click from the menu bar, **Device** > **Firmware**.
Result: The Firmware Library dialog appears.
25. Depending on which factory default project you chose in the second step, select either **SAN0001/002** or **SAN0002/002**.
26. Click **Copy**.
Result: The Firmware Information dialog appears.
27. In the "Copy To" area select the Project Directory and Project Name of the project you want to transfer to the D20MX.
Result: The "Copy To" area contains the Project Directory and Project Name of the project you want to transfer to the D20MX.
28. Click **OK**, **Close** and the **door** icon
Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
29. Make a backup copy of your project.
 - 29.1. Select from the menu bar, **Project** > **Copy Project**.
Result: The Copy Project dialog appears.
 - 29.2. In the "From" area, navigate to the folder and select the project you want to transfer to the D20MX.
 - 29.3. In the "To" area, enter a new unique name for the project.
 - 29.4. Click **OK**.
Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
30. On the tree view displayed to the left, navigate to the copied project and double-click on the project name.
Result: The main window of the copied project appears.
31. Right-click on the D20 device you want to transfer and select **Properties**.
Result: The D20 Device Properties window appears.
32. Click the **Processor** tab and the **Firmware** tab. Then click **Select**.
Result: The Select a Firmware Type dialog appears. Depending on which factory default project you chose in the second step, either SAN0001 or SAN0002 will appear.
33. Select whichever of SAN0001 or SAN0002 appears and click **OK** and **OK**.
Result: A confirmation dialog appears asking if you want to make a backup copy now.
34. Click No because you have already made a backup.
Result: Messages will appear indicating the upgrade is in progress. Messages appear in the Device Log indicating the results of the upgrade. The D20 device appears with a red dot.
35. Review all warnings and make corrections as needed, reviewing the original copy to retrieve values that may have been replaced with default values during the upgrade

36. Right-click on the device and click **Generate**.
Result: The device is displayed without a red dot.
37. Right-click on the device and click **Archive > Save**.
Result: The Save Device to ZIP File dialog appears.
38. In the "Save To" area, click the **folder** icon.
Result: A dialog appears with the title "Select a directory in which to save the project".
39. Navigate to a folder on your PC where you would like to save the device archive and click **Select** and **OK**.
40. Close ConfigPro.
41. Migrate the D20 Device Archive into SGConfig using the Migration Wizard (Refer to the Migration Wizard screencast).

Updating a D200 configuration to use the D20MX firmware definition with ConfigPro

Prerequisites

Before you can update the firmware definition of a D200 device configuration, the following components must be present

- ConfigPro 5.03 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075 V120) installed in a CD/DVD drive of the configuration computer.

Procedure

NOTICE

Migrating a multi-processor D200 will only transfer the application configurations on the first processor.

This is manually resolved by moving applications from other processors to the first processor using the ConfigPro device editing functions BEFORE converting the device to a D20 in the instructions below.

Single and multi-processor D200 devices must first be changed into D20 devices before the D20MX firmware definition can be selected.

To change a D200 device into a D20 device perform the following steps:

1. Start ConfigPro 5.03 or higher.
Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
2. Make a backup copy of the project you want to transfer to the D20MX.
 - 2.1. Select from the menu, **Project > Copy Project**.
Result: The Copy Project dialog appears.
 - 2.2. In the "From" area, navigate to the folder and select the project you want to transfer to the D20MX.
 - 2.3. In the "To" area, enter a new unique name for the project.
 - 2.4. Click **OK**.
Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
3. On the tree view displayed to the left, navigate to the project and double-click on the project name.
Result: The main window of the copied project appears

4. Right-click on the D20 device you want to transfer and select **Tools > Change**.
Result: The Change Device window appears.
5. Select type **D20** and click **OK**.
6. Follow the steps in section: "Updating a D20 configuration to use the D20MX firmware definition with ConfigPro" on page 78.

Software (feature) licensing

Version 1.2 of the D20MX introduces the Software (or Feature) licensing capabilities. The application image file contains all the applications currently available for the D20MX. Some of these applications are licensed and are not available until they are unlocked.

These licensed applications are in groups, called application groups, and are identified by a license code.

Currently only application group "001" is available. Future releases of the application image file will have more groups.

Use the D20M Shell command:

- **swlic-report** to view the list of application groups.
- **swlic-list** to view the applications in each group.

Enable trial period

An application group may be temporarily enabled for a 30-day trial period.

To enable a trial, use the command **swlic-trial -id 001** to enable application group 001.

For example:

```
D20M> swlic-trial -id 001
Trial license for '001' will be valid until 2013-03-18 (30 days)

Are you sure you want to enable the trial license for '001' [y/N] : y
INFO : Trial License '001' enabled until 2013-03-18
```



NOTE

The D20MX must be rebooted for the trial period to take effect

View the license status

The D20M Shell command **swlic-report** lists the status of the license. Each license group is listed.

For example:

```
D20M>swl i c-report
License Report Utility v01.000

License Information
=====
Target Unit           : D20MX
Serial Number         : 526-3003-000001
Customer              : Utility ABC
License created from   : D400 Utilities V1.0.1
License Version       : 01.000

Application License                               Status
=====
001 : D2X Classic Applications                     Trial Disabled
```

Unlock an application group

To unlock an application group, an unlock code must be purchased from GE. Please contact Customer Service for the unlock code. Customer Service will ask for the 'Hardware Identifier' of the D20MX that is to have the application group unlocked. This is a unique identifier for each D20MX and cannot be used with any other D20MX (that is, the license is non-transferrable).

View the hardware identifier

Use the D20M Shell command **swlic-info** to view the Hardware Identifier. For example:

```
D20M>swl i c-i nfo
System Information
License Information Utility V01.000
```

```
=====
```

```
Target Unit           : D20MX
Hardware Identifier    : 303064303163306237323461
License File          : /tffs0/swLicense/License.key: Good
```

Customer Service will send you either:

- An unlock code
- An new license file (license.key)
- Or a batch file (batch.lic) which can be used on multiple D20MXs

Unlock code

If Customer Service send an unlock code, use the D20M Shell command **swlic-unlock -l <unlock code>** to unlock the application group.

For example:

```
D20M>swl i c-unl ock -l 6E62385170303537533061626B66706643673D3D
Unl ock Key i s Val i d
Info : License for '001' and been unl ocked
```

This unlocks the application group 001.

License file

If Customer Service sends a license file (license.key), use a SCP (Secure Copy) application, such as WinSCP, to copy the license file over the network to the /ram directory on the D20MX.

Alternatively, use the D20M Shell **RZ** command to download the license file via Z-Modem through the console port. The RZ command automatically places the file in the /ram directory.

The file must be named **license.key**.



NOTE

Use the D20M Shell command **CL** (Copy License) to process the license file. This command copies the license file to the correct location on the D20MX, and if there are no errors, the D20MX automatically restarts.

For example:

```
D20M>c l
Found License file (/ram/License.key) - copyi ng
copyi ng file /ram/License.key -> /tffs0/swLicense/License.key
License file copied -- rebooti ng ....
```

Batch file

If Customer Service sends a batch file (batch.lic), use a SCP (Secure Copy) application, such as WinSCP, to copy the batch file over the network to the /ram directory on the D20MX. Alternatively, use the D20M Shell **RZ** command to download the license file via Z-Modem through the console port. The RZ command automatically places the file in the /ram directory.



The file must be named **batch.lic**.

Use the D20M Shell command **CL** (Copy License) to process the batch file. This command processes the /ram/batch.lic file, extracting the appropriate license block and creates a new license file (license.lic). If there are no errors, the D20MX automatically restarts.



For the batch file to be processed, a license file must be in place. Use the command **swlic-info** to verify a license file is in place.

For example:

```
D20M>cl
Found Batch file (/ram/batch.lic) - processing
copying file /ram/batch.lic -> /tffs0/swLicense/batch.lic
Batch License Installation '/tffs0/swLicense/batch.lic'
Searching for serial number '526-3003-000001'
License Found in Batch File
copying file /ram/newLicense.key -> /tffs0/swLicense/License.key
Success : Success License file updated
```

D20MX Processor

Chapter 6: Using the D20MX

The D20MX operation can be monitored and accessed through:

- Operational status LEDs
- LAN port status LEDs
- Fiber optic status port LEDs









Front panel LEDs

Once the D20MX is powered up, the LED indicators on the front panel become active. The indicators provide status information on the operation of the D20MX.

Operational status LEDs







The status LEDs indicate the unit's operational status:

LED Display	Label	Color	Status Description
<div><div>IRIG</div><div><div></div><div></div></div><div>PWR</div><div><div></div><div></div></div><div>RDY</div></div>	PWR	Green	Power Solid light when 5 V DC power is correctly supplied to the processor board. OFF when 5 V DC is not present.
<div><div>IRIG</div><div><div></div><div></div></div><div>PWR</div><div><div></div><div></div></div><div>RDY</div></div>	RDY	Green	Ready Flashes when Initialization (boot-up and self-diagnostics) of the D20MX is complete and the unit is ready to process data.

LED Display	Label	Color	Status Description
 IRIG  PWR  RDY  RDY	IRIG	Green	Flashes when an IRIG-B format time synchronization signal has been supplied to the unit and has been used to set the D20 system clock. Note: When removing IRIG-B signal, the LED keeps blinking for up to a minute before turning off.
 IRIG  PWR  RDY  RDY		Green	Normally off; reserved for future expansion.









LAN port status LEDs

The LAN Port Status LEDs provide a visual indication of the status for the Ethernet communication ports on the front of the D20MX.

LED Display	Label	Color	Status Description
 LINK  ACT 	LINK	Orange for 1000BASE-T. Green for 10/100BASE-T	Link 1, Link 2 Solid light when an active device is connected to the Ethernet port.
 LINK  ACT 	ACT	Yellow	Activity 1, Activity 2 Flashes when data is transmitted or received on the channel.

Fiber optic port status LEDs

The fiber optic port status LEDs provide a visual indication of the status for fiber optic ports 1 and 2.

LED Display	Label	Color	Status Description
 ACT 1  ACT 2  LINK 1  LINK 2	LINK 1 LINK 2	Green	Link 1, Link 2 Solid light when an active device is connected to the fiber optic port.
 ACT 1  ACT 2  LINK 1  LINK 2	ACT 1 ACT 2	Yellow	Activity 1, Activity 2 Flashes when data is transmitted or received on the channel.

D20MX Processor

Chapter 7: Servicing the D20MX

The D20MX does not require scheduled maintenance.
This chapter describes how to inspect the unit and remove the D20MX processor.

Performing periodic inspection

Periodic inspection is recommended to ensure that:

- The device has sustained no accidental physical damage
- Connectors and cables are intact and firmly attached

Removing the D20MX processor module

The D20MX can be removed from a non-VME (GE part number 500-0305) or VME (GE part number 500-0280) D20 chassis.

NOTICE

**To remove the D20MX
from a D20 chassis**

1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: "Grounding the D20MX" on page 38.
1. Power down the D20 and disconnect the power supply.
2. Disconnect all communication cables from the front panel of the D20MX and the backplane of the D20 chassis.
3. Loosen the front panel retaining screws.
4. Remove the blank plates located above and below the D20MX.
5. Slide the D20MX partially out.
6. For the D20MX Non-VME with Dual 100Base-FX Fiber Optic Card (526-3005LF) only:
 - 6.1. Disconnect the 975-1236 cable (connecting the fiber optic daughter card) from connectors J3 and J4 on the D20MX processor module.
 - 6.2. Loosen the D20MX fiber card front panel retaining screws.
 - 6.3. Carefully slide out the D20MX fiber card partially.

- 6.4. Remove the 975-1236 cable through the middle slot in the chassis.
- 6.5. Store the D20MX fiber card in static-protective packaging.
7. Grasp the D20MX by the front handles and slide the processor module all the way out of the D20 chassis.



Allow the D20MX to cool before removing. The heatsink of the D20MX may be extremely hot during and immediately after operation. Use caution when removing the processor module from the chassis to avoid being burned.

8. Store the D20MX in static-protective packaging.

D20MX Processor

Appendix A: Default Role-Based Access Control Model

Configured roles in the D20MX

When you configure the D20MX to use RADIUS, the D20MX must be configured with a set of roles in the B014 RADIUS Roles Table (B014RADR) of the WESMAINT II+ application (Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for more information). The role is identified by a role ID, which is an integer number provided by the RADIUS server.

The D20MX Default configurations SAG0001 and SAG0002 include a default role-based access control model that meets the general rules shown in Table 22.

Table 22: General access control rules

Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
Can Change Passwords	Yes	No	No	No
Can Clear the Login Buffer	No	No	No	No
Can Change SCADA Settings	Yes	Yes	No	No
Can Download Firmware	Yes	Yes	No	No
Can Perform Operational Control (e.g. breaker operation)	Yes	Yes	Yes	No
Can View Operational Data	Yes	Yes	Yes	Yes
Can Access Low Level "C" Shell	Yes	No	No	No

The Shell access level roles are provided in Table 23

Table 23: Shell access level

Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
Access Level	Read/Write	Maintenance	Read Only	Read Only

The specific flags defined in the Application Control field of the RADIUS Roles table are provided in the tables listed in Table 24.

Table 24: List of configured roles

Table Number	Access	Flags For...	Associated Application #
Table 25	Modify	WESMAINT	14
Table 26	Read		
Table 27	Modify	D20AC WESMAINT II+ Display Screens	32045
Table 28	Read		
Table 29	Modify	Prologic display	36
Table 30	Read		
Table 31	Modify	DNP DPA Configuration Display	32021
Table 32	Read		
Table 33	Modify	Internet Statistics Display	162
Table 34	Read		
Table 35	Modify	DNP Serial Data Link Display	32013
Table 36	Read		
Table 37	Modify	Modbus DCA Display	59
Table 38	Read		
Table 39	Modify	Modbus DPA Display	68
Table 40	Read		
Table 41	Modify	File Upload Interface	32071
Table 42	Read		
Table 43	Modify	SOE Logger	27
Table 44	Read		
Table 45	Modify	SEL DCA	78
Table 46	Modify	IEC 60870-5-101/104 DPA	101
Table 47	Read		
Table 48	Modify	Landis & Gyr 8979 DPA	185
Table 49	Read		
Table 50	Modify	Harris 6000/XA-21 DPA	199
Table 51	Read		
Table 52	Modify	IEC 60870-5 FT1.2 Balanced Data Link	32085
Table 53	Read		

Table 25: Modify access flags for WESMAINT (Application number: 14)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Time and Date display	Yes	Yes	Yes	No
1	Peripheral Status display	Yes	Yes	Yes	No
2	Peripheral Status Detail display	Yes	Yes	No	No
3	COS Buffer display	Yes	Yes	Yes	No
4	SHELL	Yes	Yes	Yes	No
5	Digital Inputs display	Yes	Yes	Yes	No
6	Digital Inputs Detail display	Yes	Yes	Yes	No
7	Digital Outputs display	Yes	Yes	Yes	No

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
8	Digital Outputs Detail display	Yes	Yes	Yes	No
9	Analog Inputs display	Yes	Yes	Yes	No
10	Analog Inputs Detail display	Yes	Yes	Yes	No
11	Analog Outputs display	Yes	Yes	Yes	No
12	Analog Outputs Detail display	Yes	Yes	Yes	No
13	Transition Counter display	Yes	Yes	Yes	No
14	Transition Counter Detailed display	Yes	Yes	Yes	No
15	SOE Buffer display	Yes	Yes	Yes	No
16	USER LOG display	Yes	No	No	No
17	Database Synch display	Yes	Yes	Yes	No
18	Switch-over display	Yes	Yes	Yes	No
19	System Status display	Yes	Yes	No	No
20	Communication Status display	Yes	Yes	No	No
21	Complex Object display	Yes	Yes	No	No
22	Complex Object Detail display	Yes	Yes	No	No
23	Generic Data display	Yes	Yes	No	No
24	Generic Data Detail display	Yes	Yes	No	No
25 - 31	Not used.	Yes	Yes	No	No

Table 26: Read access flags for WESMAINT (Application number: 14)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Time and Date display	Yes	Yes	Yes	Yes
1	Peripheral Status display	Yes	Yes	Yes	Yes
2	Peripheral Status Detail display	Yes	Yes	Yes	Yes
3	COS Buffer display	Yes	Yes	Yes	Yes
4	SHELL	Yes	Yes	Yes	Yes
5	Digital Inputs display	Yes	Yes	Yes	Yes
6	Digital Inputs Detail display	Yes	Yes	Yes	No
7	Digital Outputs display	Yes	Yes	Yes	Yes
8	Digital Outputs Detail display	Yes	Yes	Yes	No
9	Analog Inputs display	Yes	Yes	Yes	Yes
10	Analog Inputs Detail display	Yes	Yes	Yes	No
11	Analog Outputs display	Yes	Yes	Yes	Yes
12	Analog Outputs Detail display	Yes	Yes	Yes	No
13	Transition Counter display	Yes	Yes	Yes	Yes
14	Transition Counter Detailed display	Yes	Yes	Yes	No
15	SOE Buffer display	Yes	Yes	Yes	Yes
16	USER LOG display	Yes	Yes	No	No
17	Database Synch display	Yes	Yes	Yes	No
18	Switch-over display	Yes	Yes	Yes	No
19	System Status display	Yes	Yes	Yes	Yes
20	Communication Status display	Yes	Yes	Yes	Yes
21	Complex Object display	Yes	Yes	No	No

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
22	Complex Object Detail display	Yes	Yes	No	No
23	Generic Data display	Yes	Yes	No	No
24	Generic Data Detail display	Yes	Yes	No	No
25-31	Not used.	Yes	Yes	No	No

Table 27: Modify access flags for D20AC WESMAINT II+ display screens (Application number: 32045)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 28: Read access flags for D20AC WESMAINT II+ display screens (Application number: 32045)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	D20 AC Main Menu	Yes	Yes	Yes	Yes
1	Circuit Display Page	Yes	Yes	Yes	Yes
2	Circuit Configuration Page	Yes	Yes	Yes	Yes
3	D20 AC Configuration Page	Yes	Yes	Yes	Yes
4 – 31	Not Used	Yes	Yes	Yes	No

Table 29: Modify access flags for Prologic display (Application number: 36)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 30: Read access flags for Prologic display (Application number: 36)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Connect to Prologic Editor	Yes	Yes	Yes	No
1	Request Control of Port	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

Table 31: Modify access flags for DNP DPA configuration display (Application number: 32021)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-23	Not Used	Yes	Yes	Yes	No
24	Modify Points / Detail Displays	Yes	Yes	Yes	No
25-31	Not Used	Yes	Yes	Yes	No

Table 32: Read access flags for DNP DPA configuration display (Application number: 32021)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	DNP DPA Display	Yes	Yes	Yes	Yes
1-22	Not Used	Yes	Yes	Yes	No
23	Configuration Pages	Yes	Yes	Yes	Yes
24	Detail Pages	Yes	Yes	Yes	No
25 - 31	Not Used	Yes	Yes	Yes	No

Table 33: Modify access flags for internet statistics display (Application number: 162)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 34: Read access flags for internet statistics display (Application number: 162)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 35: Modify access flags for DNP serial data link display (Application number: 32013)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 36: Read access flags for DNP serial data link display (Application number: 32013)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 37: Modify access flags for Modbus DCA display (Application number: 59)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 38: Read access flags for Modbus DCA display (Application number: 59)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

Table 39: Modify access flags for Modbus DPA display (Application number: 68)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 40: Read access flags for Modbus DPA display (Application number: 68)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 41: Modify access flags for file upload interface (Application number: 32071)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 42: Read access flags for file upload interface (Application number: 32071)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	yes	No

Table 43: Modify access flags for SOE Logger (Application number: 27)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 44: Read access flags for SOE Logger (Application number: 27)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

Table 45: Modify access flags for SEL DCA (Application number: 78)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0 - 1	Not Used	Yes	Yes	Yes	No
2	Gateway access to serial port	Yes	Yes	Yes	No
3 - 31	Not Used	Yes	Yes	Yes	No

Table 46: Modify access flags for IEC 60870-5-101/104 DPA (Application number: 101)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Not Used	Yes	Yes	Yes	No
1 - 31	Not Used	Yes	Yes	Yes	No

Table 47: Read access flags for IEC 60870-5-101/104 DPA (Application number: 101)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Any Page	Yes	Yes	Yes	Yes
1 - 31	Not Used	Yes	Yes	Yes	No

Table 48: Modify access flags for Landis & Gyr 8979 DPA (Application number: 185)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Not Used	Yes	Yes	Yes	No
1	Force / Unforce Point, Delete All or Delete to Cursor in SOE Log Display	Yes	Yes	Yes	No
2	Freeze Accumulator	Yes	Yes	Yes	No
3 - 31	Not Used	Yes	Yes	Yes	No

Table 49: Read access flags for Landis & Gyr 8979 DPA (Application number: 185)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Main Display	Yes	Yes	Yes	Yes
1	Analog Input Display	Yes	Yes	Yes	Yes
2	ADC Reference Display	Yes	Yes	Yes	Yes
3	Indication, SOE or Digital Input Display	Yes	Yes	Yes	Yes
4	Accumulator Display	Yes	Yes	Yes	Yes
5	SOE Log Display	Yes	Yes	Yes	Yes
6	Analog Output Display	Yes	Yes	Yes	Yes
7	Digital Output Display	Yes	Yes	Yes	Yes
8	LRU Configuration Display	Yes	Yes	Yes	Yes
9	Cross References Display	Yes	Yes	Yes	Yes
10 - 31	Not Used	Yes	Yes	Yes	No

Table 50: Modify access flags for Harris 6000/XA-21 DPA (Application number: 199)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Not Used	Yes	Yes	Yes	No
1	Not Used	Yes	Yes	Yes	No
2	Not Used	Yes	Yes	Yes	No
3	Force Digital Output (Digital Output Display)	Yes	Yes	Yes	No
4	Not Used	Yes	Yes	Yes	No
5	Not Used	Yes	Yes	Yes	No
6	Force Analog Output (Analog Output Display)	Yes	Yes	Yes	No
7	Force R/L Output (R/L Outputs Display)	Yes	Yes	Yes	No
8	Delete All COS (COS Display)	Yes	Yes	Yes	No
9	Delete All SOE (SOE Display)	Yes	Yes	Yes	No
10 - 31	Not Used	Yes	Yes	Yes	No

Table 51: Read access flags for Harris 6000/XA-21 DPA (Application number: 199)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Main Display	Yes	Yes	Yes	Yes
1	Port Assignment and Cross References Displays	Yes	Yes	Yes	Yes
2	Current Status Display	Yes	Yes	Yes	Yes
3	Digital Output Display	Yes	Yes	Yes	Yes
4	Accumulator Display	Yes	Yes	Yes	Yes
5	Analog Input Display	Yes	Yes	Yes	Yes
6	Analog Output Display	Yes	Yes	Yes	Yes
7	R/L Outputs Display	Yes	Yes	Yes	Yes
8	COS Display	Yes	Yes	Yes	Yes
9	SOE Display	Yes	Yes	Yes	Yes
10 - 31	Not Used	Yes	Yes	Yes	No

Table 52: Modify access flags for IEC 60870-5 FT1.2 Balanced Data Link (Application number: 32085)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Not Used	Yes	Yes	Yes	No
1 - 31	Not Used	Yes	Yes	Yes	No

Table 53: Read access flags for IEC 60870-5 FT1.2 Balanced Data Link (Application number: 32085)

Bit Position	Description	Administrator [2]	Engineer [1]	Operator [3]	Observer [0]
0	Any Page	Yes	Yes	Yes	Yes
1 - 31	Not Used	Yes	Yes	Yes	No

D20MX Processor

Appendix B: Standards & Protection

This Appendix lists the standards with which the D20MX has been tested for compliance.

Compliance standards

Compliance standards are listed for the following categories:

- Emission standards; see Table 54
- Immunity standards; see Table 55
- Safety publications; see Table 56
- Environmental standards; see Table 57

Table 54: Emission standards

Standard Name	Description	Test Specification
EN55011 (CISPR 11) ¹	ISM RF equipment – Electromagnetic disturbance characteristics	Radiated Emissions 30 MHz to 1 GHz Conducted Emissions 150 kHz – 30 MHz

Table 55: Immunity standards

Standard Name	Description	Test Specification
IEC 61000-4-2	Electrostatic discharge (ESD) immunity test	Contact Discharge: 8 kV Air Discharge: 15 kV HCP and VCP: 8 kV
IEC 61000-4-3 IEC 61850-3: clause 5.7.2	Radiated, radio-frequency electromagnetic field immunity test	80 MHz to 1 GHz: 10V/m 1.4 GHz to 2 GHz: 3V/m 2 GHz to 3 GHz: 1V/m
IEC 61000-4-4 IEC 61850-3: clause 5.7.1.4	Electrical fast transient/burst immunity test	Direct Couple: 4 kV/5 kHz Capacitive Clamp: 2 kV/5 kHz
IEC 61000-4-5	Surge immunity test	

Standard Name	Description	Test Specification
IEC 61000-4-6 IEC 60255-22-6 IEC 61850-3: clause 5.7.1.1	Immunity to conducted disturbances, induced by radio-frequency fields	150 kHz to 80 MHz: 10Vrms
IEC 60255-22-1	1 MHz burst immunity test	
IEC 61000-4-8	Power frequency magnetic field immunity test	
IEC 61000-4-9	Pulse magnetic field immunity test	
IEC 61000-4-12	Ring wave	
IEC 61000-4-11	Voltage dips, short interruptions and voltage variations immunity tests	
IEC 61000-4-16 IEC 61850-3: clause 5.7.1.3	Test for immunity to conducted, common mode disturbances in the frequency range 0 Hz to 150 kHz	30Vrms, 300Vrms
IEC 61000-4-17	Ripple on DC input power port immunity test	
IEC 61000-4-29+	Voltage dips, short interruptions and voltage variations on DC input power port immunity test This standard only applies when using high voltage DC as the source (100 V DC to 300 V DC).	

Table 56: Safety publications

Standard Name	Description	Test Specification
IEC 61010-1	Safety requirements for electrical equipment for measurement, control and laboratory use - General requirements	
IEC 60255-5	Insulation coordination for measuring relays and protection equipment- Requirements and tests	Dielectric and Resistance measurements not applicable due to design (TVS in circuit)

Table 57: Environmental standards

Standard Name	Description	Test Specification
IEC 60068-2-1	Cold	144 hours powered at - 20 °C
IEC 60068-2-2	Dry Heat	144 hours powered at + 70 °C
IEC 60068-2-6	Vibration (sinusoidal)	A logarithmic sweep from 10 Hz to 150 Hz to 10 Hz at 1 oct/min for 1 sweep cycle in the 3 orthogonal axes. Acceleration level 1 g
IEC 600255-21-2	Shock - Operating Response Test Shock - Non-Operating Withstand Test	Pulse shape: Half sine Pulse duration: 11 ms - Operating Response Test: Acceleration level: 5 g's - Non-Operating Withstand Test: Acceleration level: 15 g's 3 pulses per polarity per axis for a total of 18 pulses
IEC 600255-21-2	Bump - Non operating test	Pulse shape: Half sine Pulse duration: 16 ms Acceleration level: 10 g's 1000 pulses per polarity per axis for a total of 6000 pulses
IEC 60068-2-30	Damp heat, cyclic (12 h + 12 h cycle)	

Standard Name	Description	Test Specification
IEC 60068-2-31	Drop and topple	Dropping on each face Dropping on each corner Toppling (or pushover) For a total of 12 drops
IEC 60068-2-78	Humidity Testing	96 hours steady state humidity at 40 °C and 93% RH

1 To comply, the ferrite clamp (460-0073) supplied must be installed on the power cable.

D20MX Processor

Appendix C: Frequently Asked Questions

This appendix answers some frequently and commonly asked D20MX questions.

Questions and answers

Q: Why is a D20MX RTU important?

A: The D20MX is being introduced for the following reasons:

- Some electronic components used in the D20 products have reached their end-of-life; For example, the 68EC030 CPU in the D20ME II and D20ME boards.
- Vxworks is the new operating system for the D20MX; this is more robust for D20 applications.
- The D20MX offers Cyber Security features that are intended for critical infrastructure protection within the power system. This is required for Electric Reliability Compliance.
- The D20MX is a modern platform that is capable of handling current and future processing needs, particularly for security.
- The D20MX has 1 GB of RAM, compared to 1 MB RAM in the D20ME.
- The D20MX has 16 MB of built-in NVRAM, compared to the 512 KB of NVRAM available in its predecessor. Subsequently, there is no need for additional memory expansion modules.
- The firmware flash memory size in the D20MX is 128 MB, compared to the 2 MB of its predecessor.
- The D20MX uses a Super Capacitor which allows the system clock to be saved for 14-days even after power off.

Q: How does configuration storage work in the D20MX?

A: The Super capacitor strictly allows the retention of the system clock time for 14-days. At power-up, the configuration resides in the RAM. At power-down, configuration resides in the flash. This is possible due to the seamless transaction between the RAM and flash. This arrangement protects the D20MX configuration from being lost, even after power-down for an indefinite period of time.

Q: Why does the D20MX use the Vxworks Operating System instead of PSOS?

A: Vxworks is designed for mission critical systems. It is purpose-fit, extremely robust and fast. It is industry-focused and designed to work with real-time operating systems. It is the new operating system of choice for numerous embedded systems that require a high level of robustness.

A: Embedded systems manufacturers are moving away from the PSOS operating system since on-going support for this operating system is very limited.

Q: Is the D20MX hardware backward compatible?

A: The D20MX hardware is compatible with the I/O modules installed in the field.

A: Due to aging printed circuit board assembly and mechanical constraints, only certain chassis from 2002 and onward can be used with a D20MX. This comprises the following chassis:

- D20 VME chassis 500-0280 Release 08 or higher

For the VME chassis 500-0280, the zero volt cable supplied with the D20MX KIT, must be connected from the zero volt TB2 terminal block on the 517-0225 to zero volt on the 517-0123. Review the hardware manual for the steps involved. Part number for the zero volt wire cable is 975-1237.

- D20 Non-VME chassis 500-0305 Release 18 or higher

Q: Are the PCOMMON versions compatible with the D20MX?

A: The following PCOMMON versions are compatible with the D20MX:

- -P022 v3.0x5 and 3.00: PCOMMON for D20C
- -P010 v3.0x6, 3.05, 3.01 and 3.00: PCOMMON for D20A, D20S and D20K
- -P087 v1.04, 1.03 and 1.02: pBOOT for D20AC

Also see the PCOMMON versions compatible with the D20MX in Table 9 on page 23.

Q: What is the recommended operating temperature range of the D20MX?

A: The operating temperature range is 0°C to +70°C.

Note: Do not operate the D20MX above 60°C for extended periods of time as this shortens the life of the super capacitor and reduces the backup time of the real time clock.

Q: What software application is used to configure a D20MX configuration?

A: The SGConfig (version 7.2 or higher) offline configuration tool is used to configure the D20MX. SGConfig is similar to ConfigPro which is used to program its predecessor.

Q: Can you migrate an old D20/D200 configuration to D20MX?

A: ConfigPro is partly used to get the D20 device configuration ready for migration into the SGConfig tool.

A: It is recommended to migrate a project rather than a device to prevent partial loss of configuration data related to Ethernet/LAN.

A: For detailed migration steps, see section “Transfer D20/D200 configurations to the D20MX” on page 70.

D20MX Processor

Appendix D: Using ConfigPro with D20MX

While SGConfig is recommended for configuring and transferring a D20 configuration to the D20MX, it is also possible to configure the D20MX using ConfigPro.

This appendix describes how to transfer a D20 configuration to the D20MX using ConfigPro.

Refer to the “Application definition files and default configurations” on page 128 to see how application definition files and factory default configuration files can be installed.


Using ConfigPro to configure and transfer a D20 configuration to a D20MX is done by:

- “Transferring D20 configurations to the D20MX” on page 104
- “Downloading a D20MX configuration” on page 119


Transferring D20 configurations to the D20MX

To transfer a D20 configuration to the D20MX using ConfigPro:

1. Create a D20MX device.
 - 1.1. Right-click the D20 device.
 - 1.2. Select **Copy....**
- Result: The **Select Project and Page to Copy Device to** window appears.



- 1.3. In the **Device Name** field, rename the device as a D20MX device.



2. Generate a report of the applications in the original D20 device configuration and determine the unused applications.
 - 2.1. Right-click on the created D20MX device and select **Reports > Application List**.
Result: The Select Reports dialog appears with the Application List report selected.
 - 2.2. Click **Setup**.
Result: The Print Setup dialog appears.
 - 2.3. Select a printer in the **Name** field if the Name field is empty.
Result: A printer is selected in the Name field.
 - 2.4. Click **OK** and **OK**.
Result: A new tab named Application List opens and contains the Application List report for the original D20 device.
 - 2.5. Compare the Application List report with Table 2 D20MX application definitions on page 16. With the exception of IP Redundancy Monitor (B152-1), note the applications that appear in Table 2 but not in the report. You may want to print Table 2 and mark these applications. These applications are referred to as "unused" applications in the steps to follow.
 - 2.6. Click the Door icon to close the Application List report.
Result: The project containing the created D20MX device reappears.
3. Edit the device properties of the created D20MX device so that it uses an appropriate D20MX SAN firmware file and it has similar device properties to the desired D20MX factory default configuration.

The D20MX SAN firmware files exist in two forms:


- SAN0001 contains the latest versions of all applications and should be used in all new configurations.
- SAN0002 contains older versions of the Mailbox DTA [B009] and DNP v3.00 DPA [B021] and is required for systems with older applications. For more details, see Table 2, "D20MX application definitions," on page 16.

- 3.1. Select the factory-based D20MX configuration file to be restored.

- 3.1.1. Right-click the D20MX device.


- 3.1.2. Select **Archive > Restore**.

Result: The Select a Device Zip file to Restore window appears.




- 3.1.3. Navigate to the factory default configuration files which were staged previously.

The listed factory-default configuration files with a .zip extension were built with ConfigPro.




- 3.2. Select a project location to which the configuration file is to be restored.


Note: The D20MX factory default configuration files are ConfigPro 5 based. If using ConfigPro 6 or 7, when prompted to upgrade, select **Yes**. By restoring the factory D20MX device to the same project location as the renamed D20 [D20MX device] in step 1.3, this will eliminate the need to copy the SAN firmware to make it available in the firmware library - as described in step 3.3.




If a message indicates that a nested loop [project] will be created, choose a different Project directory as required: e.g., C: drive in the screen capture that follows.




Note: Step 3.3 applies because the D20MX factory default configuration was restored to a different project location - C: drive, as shown above. If this is not the case, right-click on an empty space within the project's main page and click on **Firmware** to confirm that the SAN0001/02 firmware has been automatically added to the list of firmware within the firmware library, then proceed to step 3.4.




- 3.3. Open the restored factory default configuration file.
 - 3.3.1. Navigate to the project directory where the factory default configuration was restored.
 - 3.3.2. Open the file.
 - 3.3.3. Use the **Projects** and **Windows** tab to switch screen content. The Windows tab allows access to different projects.






As shown above, the device properties of the factory default configuration **10730-02** uses **SAN0001**.


- 3.3.4. Right-click on the factory default configuration's main page and select **Firmware**.




- 3.3.5. Select the required SAN firmware and click **Copy** to transfer this firmware to the project location in step 1.



This is the location of the copy of the D20 device being modified. In step 1, this D20 device was copied and renamed as a D20MX device.



Result: The D20MX device location now has a firmware library that contains the SAN firmware transferred from the previous step.




- 3.4. Select the D20MX device created in step 1 [copied and renamed D20 device], which is to use the intended SAN firmware in the firmware library.


3.4.1. Right-click on the D20MX device.

- 3.4.2. Select the **Processor** tab > **Firmware** tab > Use **Firmware Type** check-box to choose the SAN0001 firmware.

Result: The Select a Firmware Type window appears. Click **OK**.




- 3.4.3. Confirm the SAN0001/SAN0002 firmware is now associated to the D20MX device (from step 1).



- 3.5. Manually set the D20MX processor card.


Note: In the same device properties, the General tab does not include a D20MX processor card.



- 3.5.1. Use the memory model settings from the factory default configuration as a reference, See the table below.

D20MX Processor Memory Model - Set Manually			
EPROM Base	60000000 [HEX]	EPROM Size	10000000 [HEX]
NVRAM Base	50010000 [HEX]	NVRAM Size	00FF0000 [HEX]
RAM Base	00000000 [HEX]	RAM Size	40000000 [HEX]

- 3.5.2. Manually set the memory model in the D20MX device being modified by selecting the **Processor** tab > **Memory Model** tab > **Set Manually** option.




Step 3.6 is applicable if the device configuration were a “LAN-based Device” configuration. LAN-based device in the device properties must first be selected under the main General tab. It is impossible to have a LAN-based device unless the project itself is a LAN-based project with all network addresses and settings clearly defined for LAN A and/or B. Step 3.6 assumes that the reader is familiar with the complete ConfigPro LAN settings configuration steps and that these steps have already been considered. It points out the D20MX factory default LAN-settings.

- 3.6. Set the LAN Settings.

Default LAN-Based Important Settings: Notice that the D20MX factory default configurations are LAN-based. This is because the hardware of the D20MX RTU has built-in LAN functionality by default. Subsequently, no extra Media Interface Card or EME card is needed.


- 3.6.1. For LAN-based D20MX configurations, ensure that the **BOOTP Settings** option is disabled; select the **Not Used** option.



3.6.2. The **Services** settings highlighted below are required for remote connection into the RTU. Although the defaults for WesmaintSSH and CommandSSH are 22 and 922 respectively, these ports can be changed to customized numbers:


- **WesmaintSSH** allows remote access to the wesmaint menu.
- **CommandSSH** allows remote access to the command prompt > D20M prompt.

These are both TCP connections.




4. Click **OK** when the D20MX device properties are set.

Result: The applications present in the SAN firmware are applied to this new D20MX device.




5. Carefully configure the applications of interest before generating the tables for the D20MX device. Disable unused applications.
- 5.1. In the D20MX device from step 1, disable the unused applications identified in step 2.
 - 5.2. Configure the Wesmaint II+ [B014-1N V620] and System Point Database [B008-1 V3.11] applications.




- 5.3. Configure the new **Wesmaint II [B014-1N V620] application** referring to its configuration guide. There are new tables and security settings that are required to be configured. For complete details, refer to the D20MX Documentation CD for the B014-1N configuration guide.


5.3.1. Use the D20MX factory default configuration as a reference.



- 5.3.2. Double-click on this factory default configuration and click the **System Point Database Applications** tab.




- 5.3.3. Double-click on the **Wesmaint II+** application.




- 5.3.4. Import the RADIUS roles from the D20MX default configuration into the D20MX device being modified.

While in the D20MX factory default configuration's Wesmaint II+ application, right-click on the **RADIUS Role Table [B014RADR]**. Export the settings to a location on a local drive. These settings are imported later into the same table in the newly modified D20MX device.




5.3.5. While in the D20MX device created in step 1, double-click and go to the **System Point Database** tab which contains the Wesmaint II+ application. Right-click on the **RADIUS Role Table** [B014RADR] and import the B014RADR settings previously exported. Select the **B014RADR.CSV** file and click **Select**.




5.4. Configure the IP Redundancy Monitor [B152] application.

Note: If the IP redundancy [B152] application in the DCA is enabled, its pseudo point descriptions must be correctly set. Complete the following steps to ensure this.


5.4.1. Use the D20MX factory default configuration as reference.



5.4.2. Double-click this factory default D20MX configuration and go to the **System Point Database Applications** tab.




5.4.3. Double-click the **System Point Database Applications** Table. Select the **IP Redundancy Monitor** from the list of application and click **Descriptors**. Right-click the **Export** icon and export the descriptions of the four pseudo points.




5.4.4. Click **OK**.


5.4.5. Choose a location to export these descriptions to. The text file exported will be later imported into the new D20MX device being modified.




5.4.6. Go to the D20MX device being modified. Double-click the device. Navigate to the **System point database Applications** tab. Double-click the **System Point Database** application. Select the **IP Redundancy Monitor** from the list of applications. Click **Descriptors**. Click the Import icon.



5.4.7. Import the same text file [**DIDESC.TXT**] that was previously exported from the factory default D20MX device.





5.4.8. Confirm the pseudo point descriptions changed as shown below. Click **OK** to accept the change and to close each window.



- 5.4.9. Carefully configure all other enabled applications based on their respective configuration guides. This is required before a configuration can be successfully generated without errors.
- 5.4.10. Right-click the device and generate all the tables of the device. Carefully review and resolve all error and warnings.

Note: A red dot on a device indicates that the device's tables need to be generated. Unresolved errors makes the red dot remains



5.4.11. Open up the device and go to the Wesmaint II+ application to compare the RADIUS Role [RADR] tables in the factory default D20MX device with that in the newly modified D20MX device. Compare the first two columns [Role ID and Role Name] as shown below to confirm the export and import was successful. If not, repeat the export/import process.

10730-01 \ Wesmaint II+						
Icons Tables						
Role	Role ID	Role Name	Time Format	Date Separator	Date Format	Logout Time
1	0	Observer	24 hr	Hyphen	YY MM DD	300
2	1	Engineer	24 hr	Hyphen	YY MM DD	300
3	2	Administrator	24 hr	Hyphen	YY MM DD	300
4	3	Operator	24 hr	Hyphen	YY MM DD	300


BPR_MW_8-18-10B2 \ D20MXDEVICE \ Wesmaint II+						
Icons Tables						
Role	Role ID	Role Name	Time Format	Date Separator	Date Format	Logout Time
1	0	Observer	24 hr	Hyphen	YY MM DD	300
2	1	Engineer	24 hr	Hyphen	YY MM DD	300
3	2	Administrator	24 hr	Hyphen	YY MM DD	300
4	3	Operator	24 hr	Hyphen	YY MM DD	300

- Generate the device configuration, after a configuration has been properly configured.
Result: If there are no errors or warnings, the red dot on the device should not appear and the generated device is ready to be downloaded into the D20MX RTU.
- The transfer of a D20 configuration into a D20MX configuration is complete.

Configuration file in project directory



In step 5.4.10, a **D20MXDEVICE.SHX** file was created after generating the tables of this D20MX device created. This file can be found within the device directory in windows explorer.



The **D20MXDEVICE.SHX** file is the file downloaded into the D20MX during the configuration download process.

Downloading a D20MX configuration

A D20MX configuration can be downloaded either through a:

- Local [Serial] Transfer of Configuration, or a
- Remote [Secure] Transfer of Configuration

Local [serial] transfer of configuration

The local transfer of configuration can be done by either:

- "Option 1 - use ConfigPro terminal emulator and the F7 key" on page 119
- "Option 2 - Use a non-ConfigPro terminal emulator and a "dl" command" on page 122

Option 1 - use ConfigPro terminal emulator and the F7 key


Serial configuration download to the D20MX is done from within ConfigPro similar to a D20.

To use a serial connection to download a configuration to the D20MX, using the ConfigPro terminal emulator and F7 key:


1. Connect a cable; either a:
 - NULL modem cable (GE Energy part number 977-0529) from the RS-232 connector at the front panel of the D20MX to the serial communication port of the PC.

OR

- Wesmaint cable [977-0300] could be used to connect the Wesmaint port at the back of the D20MX chassis to the serial communication port of the PC.
- 2. Set up the terminal emulator with the D20MX communications parameters.
 - 2.1. From ConfigPro, select **Device > Communications > Communications Options....**
Result: The Communications Options window appears.




- 2.2. Set the communication options:
 - Baud Rate: **19200**
 - Parity: **None**
 - Data Bits: **8**
 - Stop Bits: **1**




- 2.3. Connect to the D20MX device.
 - 2.3.1. Right-click or click the device icon.
 - 2.3.2. Select **Device > Communications > Terminal Emulator**.
 - 2.3.3. Login to the D20MX terminal using the login and password. When logging into the D20MX for the first time, use the default login and password [Login: **admin** | Password: **changeme**].
Result: The D20M prompt appears.

- 2.3.4. Confirm that access is allowed by pressing the **Enter** key a couple of times.
- 2.4. Download [sync] the configuration from ConfigPro to the D20MX by pressing the F7 key on the key board.
- 2.5. Optionally you can set up the terminal emulator for faster download speed:
 - 2.5.1. Login to the D20MX device through the ConfigPro Terminal Emulator.
Result: The D20M prompt appears.
 - 2.5.2. Type **baud 115200** and press **Enter**.
Result: The D20MX baud rate changes from 19200 to 115200.
 - 2.5.3. Disconnect the D20MX from ConfigPro by selecting **Communications > Disconnect**.
 - 2.5.4. Open the communication properties by selecting **Device > Communications > Communications Options....**
Result: The Communications Options window appears.
 - 2.5.5. Change the baud rate to match 115200 by selecting the **Software Transmit** and **Software Receive** options and then clicking **OK**.



- 2.5.6. Reconnect to and login to the D20MX. See step 2.3 [Connect to the D20MX device].
- 2.5.7. Download [sync] the configuration from ConfigPro to the D20MX by pressing the **F7** key.
Result: The Download Configuration File progress bar appears.




- 2.6. Restart the D20MX device when the download is complete by clicking **Boot**.





Booting the D20MX resets it to 19200. If the baud rate in the D20MX is not the same as that in the communication properties, the command prompt shows the following characters.



If this is the case, change the ConfigPro communication properties to match the 19200 baud of the D20MX.

Option 2 - Use a non-ConfigPro terminal emulator and a "dl" command

A **D20MXDEVICE.SHX** file is created when the tables of the D20MX device are generated. See section "Configuration file in project directory" on page 118 or see step 8 [Locate the **D20MXDEVICE.SHX** file] within this section.

Serially transfer the **D20MXDEVICE.SHX** file using Tera term (a terminal emulator) to the D20MX RTU using the dl command; this is similar to the download process of a D20ME firmware configuration. This download process is done at the D20M prompt.


To download a configuration to the D20MX, using a non-ConfigPro terminal emulator and a "dl" command:

1. Connect a NULL modem cable (GE Energy part number 977-0529) from the RS-232 connector located at the front panel of the D20MX to the serial communications port of the PC or terminal.
2. Set-up a VT100 terminal emulator [e.g., Tera term Pro] with the following serial communication parameter values:


Parameter	Value
Port	COM1 or COM2, or as required by the computer being used.
Baud Rate	19200 bps
Data	8 bit
Parity	none
Stop	1 bit
Flow Control	Xon/Xoff
Transmit delay	0 msec/char; 0 msec/line



To determine the computer port used, on the computer's desk top, right-click on the **My Computer** short-cut icon and go to **Manage**. Go to **Device Manager > Ports** as shown below.



3. Login to the D20MX device. The factory default configuration for the D20MX comes with one default user account with: Username: **admin**; Password: **changeme**.
4. Navigate to the D20M prompt; this is called a SHELL prompt - an equivalent of the 68K monitor prompt.



5. Press the **Enter** key a couple of time to display and confirm the required prompt; that is, D20M.

```

Tera Term - COM6 VT
File Edit Setup Control Window Help


Welcome to the D20MX Application Monitor!
Access Level is Read/Write.
Please Wait... 1
Press Enter to Continue...

D20M>
D20M>
D20M>sp
value = 0
D20M>dl


```

6. Type **sp** to suspend the processor, then type **dl** to download and press **Enter**.
7. The **D20MXDEVICE.SHX** file located in the project directory below can simply be dragged and dropped in the Tera term window.
8. Locate the **D20MXDEVICE.SHX** file.
 - 8.1. Open Windows explorer.
 - 8.2. Navigate to the project directory where this D20MX device is located.

Note: The file name D20MXDEVICE represents the device name.



9. Drag and drop the **D20MXDEVICE.SHX** file onto the Tera term window.



Once a configuration download has been completed, it is recommended that the default user account information be changed as soon as possible. Refer to the B014-1NCG WESMAINT II+ for the D20MX - Configuration Guide for details on how to modify user accounts and how to change the password of a user. The D20MX configuration can be defaulted by pressing CTRL-F on a terminal connected over the front RS232 port during startup. In addition, if the D20MX detects a corrupt configuration on startup, it will generate a system default configuration.

The system default configuration comes with one user account: username: **recover**; password: **system**. Login with this username and synchronize a configuration to the D20MX over the front RS232 port.



The D20MX can only be accessed over the front RS232 port with the system default configuration.

If you synchronize a configuration with any of the following errors: “there are no usernames configured in the B014 User table”; “the B014 User table is disabled”, or “the B014 application definition does not match the firmware version”, then the applications will not start and you will have only serial access in **debug mode**.

Remote [secure] transfer of configuration

Since Telnet and TFTP file transfer do not provide a secure means to connect or transfer data to the D20MX RTU, they are not supported within the D20MX.

The D20MX now supports both SSH and SFTP means of connection. The D20MX RTU must be equipped with a valid IP configuration that allows computer PC connectivity.


WINSCP is an example of a commonly used tool that allows connectivity to the D20MX remotely. This can be found on the web. WinSCP downloads are available at:

<http://winscp.net/eng/download.php>


To transfer the configuration file:

1. Set your computer IP address to be in the same domain [IP address and Subnet mask] as the D20MX.
2. Close any currently opened terminal session to the D20MX.
3. Start **WinSCP**.


Result: The WinSCP Login window appears.




4. Login to WinSCP using the D20MX IP address and port number 22.




In the D20MX configuration, port 22 has been created in the Services section of the Device LAN Properties.




5. If the following window appears, click **Yes**.




6. Make a copy of the generated configuration file **D20MXDEVICE.SHX** and rename it to **device.shx**.
7. Transfer the **device.shx** file by dragging it from your computer local drive into the D20MX's ram.
Result: The Copy window appears.
8. Click **Copy**.



9. Login to the D20M prompt of the D20MX RTU - this is the SHELL [option 3] menu.




10. Suspend the processor by typing **sp** and pressing **Enter**.
11. Copy the configuration by typing **cc** and pressing **Enter**.
12. Select the configuration file by typing **sc** and pressing **Enter**.
13. Restart the D20MX device by typing **boot** and pressing **Enter**.



Application definition files and default configurations

The D20MX Documentation CD contains numerous folders and files. The three main folders for the purpose of this document are highlighted below.



In the D20MX Documentation CD contains all of the:

- Configuration guides, including the Wesmaint II+ user and configuration guides.
- Factory Default Configuration files: Application Definitions/D20MXv1_2Appldefs. The ConfigPro sub-folder contains the factory default zipped ConfigPro files.

Staging factory default configuration files

To stage the factory default configuration files so that they may be accessed by ConfigPro:

1. Press the Windows Key and **E** at the same time.
Result: The Windows Explorer window appears.
2. Navigate to a folder to which you have write permissions.
Result: The content of the folder is displayed.
3. Click the **New folder** button in Windows Explorer
Result: A new folder is created with the name "New folder" and the cursor is positioned to allow renaming of the folder.
4. Rename the folder to **D20MXV1.20**.
Result: The folder is renamed to D20MXV1.20.
5. Insert the D20MX Documentation CD in to the computer's DVD/CD drive.
Result: The Documentation CD home page appears in your default Web Browser. If this doesn't happen, navigate to the CD in Windows Explorer, and double click the **readme.html** file on the root of the CD.
6. Under the **D20MX Factory Default Configuration Files** section, click on the link named ConfigPro.
Result: The Factory Default Configuration Files folder is displayed.

7. Using Windows Explorer, copy/paste the files as shown in the following table. To copy a file, select it and press **Ctrl-C**. To paste a file, click on the Windows Explorer window showing the new D20MXV1.20 folder and press **Ctrl-V**.


Navigate to folder on D20MX Documentation CD	Copy/Paste the following files to the new folder D20MXV1.20
10730-02.zip	10730-02.zip
10731-02.zip	10731-02.zip

Result: Windows Explorer window showing the new D20MXV1.20 folder is displaying the files shown in the above table.


Installing application definitions: archived

To install the application definitions:


1. From ConfigPro, initiate the Application Installer by selecting **Tools > Application Installer**.




Result: The ConfigPro Application Installer - Welcome window appears.




2. Select the **Install all applications from archive** option and click **Next**.
Result: The ConfigPro Application Installer - Select Archive window appears.



3. Select the source directory where the application archive is stored.
 - 3.1. Navigate to the source directory: Go to the D20MX Documentation CD folder > **Configuration Files** sub-folder > **Application Definitions** folder.
 - 3.2. Select the **D20MXv1_2Appldefs** file.
 - 3.3. Click **Select**.
4. Click **Next**.
Result: The ConfigPro Application Installer - Select Destination Directory window appears.




5. Select the destination directory into which the application definitions are to be copied.
To determine the destination directory, in ConfigPro, go to **File > Preferences > Directories**. This is the path highlighted in the screen capture below
[C:\WESSYS\ApplDef]



6. Click **Next**.

Result: The ConfigPro Application Installer - Installation Complete window appears.




7. Click **Finish**.

Installing application definitions: non-archived


In the D20MX Documentation CD, the **DEFNs** folder contains the **APPLDEF** sub-folder with all the application definition files.

To install missing application definition files:

1. From ConfigPro select **Tools > Application Installer**.




Result: The ConfigPro Application Installer wizard appears.




2. Choose either of the following options:
 - Install all the applications required in a project
 - Install a number of applications YOU select.

- Click **Next**.

Result: The ConfigPro Application Installer - Select Source Directory window appears.



- Select a Source director [this is the **DEFNs/ APPLDEF** path within the D20MX Documentation CD].
- Select the **DAL100.DB** file and click **Select**. The Definitions Found field should indicate **Yes**.



6. Click **Next**.


Result: The ConfigPro Application Installer - Select a ConfigPro Project window appears.




7. Select the ConfigPro project that requires these application definitions.

8. Click **Next**.

Result: The ConfigPro Application Installer - Select Destination Directory window appears.




9. Select the destination directory into which the application definitions are to be copied. To determine the destination directory, in ConfigPro, go to **File > Preferences > Directories**. This is the path highlighted in the screen capture below [C:\WESSYS\ApplDef]



10. Click **Next**.

Result: The ConfigPro Application Installer - Installation Complete window appears.



11. Click **Finish**.

D20MX Processor

Appendix E: List of Acronyms

Acronym Definitions

This Appendix lists and defines the acronyms used in this manual.

Table 58: Acronym list

Acronym	Definition
A	Amperes, unit of measure
AEL	Accessible Emission Limit
ANSI	American National Standards Institute
ASCII	American Standard Code for Information Interchange
ASDU	Application Service Data Units
AWG	American Wire Gauge, unit of measure
bps	bits per second, unit of measure
CCU	Central Control Unit
CE Mark	Mandatory conformity mark for products placed on the market in the European Economic Area (EEA)
CISPR	Special international committee on radio interference
COM1/COM2	Communications port
CPU	Central Processing Unit
CTS	Clear To Send
dBm	decibel-milliwatt, unit of measure - an electrical power unit in decibel (dB)
DCA	Data Collection Application
DCD	Data Carrier Detect
DNP	Distributed Network Protocol
DPA	Data Processing Application
DTA	Data Transmission Application
DTE	Data Terminal Equipment
EIA	Electronic Industries Alliance
EMC	Electromagnetic Capability

Acronym	Definition
EMI	Electromagnetic Interference
EPUP	Environmental Protection Use Period
ESD	ElectroStatic Discharge
EU	European Union
FEFI	Far End Fault
FPGA	Field-Programmable Gate Array
GE	General Electric
GOF	glass optical fiber
HCS	Hard Clad Silica
HDLC	High-level Data Link Control
HMI	Human Machine Interface (also called Graphical User Interface – GUI)
Hz	Hertz, unit of measure for frequency
I/O	Input/Output
IEC	International Electrotechnical Commission Standards
IED	Intelligent Electronic Device
ILS	Instrument Landing System
in-lb	inch-pound, unit of measure for energy
IRIG-B	Inter Range Instrumentation Group (IRIG) - an American standardized network time code format
kbps	kilo bits per second, unit of measure
LAN	Local Area Network
lb	pound, unit of measure for weight
LED	Light Emitting Diode
LLA	Loss Link Alert
LRU	Logical Remote Unit
Mb	Mega bits, unit of measure
MB	Mega bytes, unit of measure
Mbps	Mega bits per second, unit of measure
MBps	Mega bytes per second, unit of measure
MCV	Maximum Concentration Values
MD5	Message Digest 5 (check data integrity)
MDI	Medium Dependent Interface
MDIX	Medium Dependent Interface, Crossover
ms	milliseconds, unit of measure
Nm	Newton-meter, measure of energy
NTP	Network Time Protocol
NVRAM	Non-Volatile Random Access Memory
PC	Personal Computer
PCBA	Printed Circuit Board Assembly
PG&E	Pacific Gas and Electric
RMA	Return Merchandise Authorization
RoHS	Restriction of Hazardous Substances
RTS	Request To Send
RTU	Remote Terminal Unit
Rx	Receive
RXD	Receive Data
SCADA	Supervisory Control and Data Acquisition

Acronym	Definition
SCP	Secure Copy application
SEL	Schweitzer Engineering Laboratories
SNTP	Simple Network Time Protocol
SOE	Sequence Of Events
SQL™	Structured Query Language
SRU	Sub-Remote Unit
TIA	Telecommunication Industries Association
Tx	Transmit
TXD	Transmit Data
UART	Universal Asynchronous Receiver-Transmitter
UTC	Universal Time Coordination
UTP	Unshielded Twisted Pair
VA	Volt Amps, unit of measure
V AC	Volts, Alternating Current, unit of measure
V DC	Volts, Direct Current, unit of measure
VME	Versa Module Eurocard

D20MX Processor

Index

A

AUTOMATIC ON-LINE STARTUP TEST	57
AUTOMATION APPLICATIONS	16

C

CABLING	
D.20 Link	43
Ethernet	44
fiber optic	45
overview	41
serial	43
CHASSIS OVERVIEW	
D20 non-VME	19
D20 VME	21
CODE FILES	58
COMMIT NEW FIRMWARE	68
COMMUNICATIONS SPECIFICATIONS	27
COMPLIANCE STANDARDS AND PROTECTION	97
CONFIGPRO	
download a D20MX configurations	119
transfer D20 configurations	104
CONFIGURATION FILES	58
CONFIGURATIONS	
transfer D20/D200	70
update D20/D200	78
CONNECT THE POWER SUPPLY	38
CUSTOMER SUPPORT	11

D

D.20 LINK CABLING	43
D20	
chassis overview	19
modems	23
peripherals	23

power supplies	22
system redundancy	49
D20 CHASSIS LAYOUTS	31
D20 NON-VME CHASSIS OVERVIEW	19
D20 VME CHASSIS OVERVIEW	21
D20MX	
connect the power supply	38
grounding	38
installation steps	33
removal steps	87
retrofit	35
unpacking	38
D20MX PROCESSOR	16
DEFAULT USER	62
DESIGN OF PRODUCT	15
DOCUMENTATION	
additional	7
audience	7
conventions	8
DOWNLOAD	
image files over network	66
software over serial	64
when	63

E

ELECTRIC SPECIFICATIONS	27
ENVIRONMENT SPECIFICATIONS	28
ETHERNET	
cabling	44
fiber optic	45
twisted-pair	44

F

FAIL-OVER CHECK	59
FIBER OPTIC	

cabling	45
port LEDs	86
FILES	
code	58
configuration	58
FIRMWARE	
commit new	68
revert old	69
upgrade	12
FIRMWARE/FPGA VERSIONS	19
FRONT PANEL LEDS	85

G

GROUNDING D20MX	38
-----------------------	----

I

IMAGE DOWNLOAD PREREQUISITES	63
IMAGE FILES	
download over network	66
INSTALLATION STEPS	33
INTRODUCTION TO SOFTWARE	61
IP ADDRESSES	46

K

KITS	25
------------	----

L

LAN PORT LEDS	86
LAN REDUNDANCY	46
LEDS	
fiber optic port status	86
front panel	85
LAN port status	86
operational status	85
LICENSING SOFTWARE	82
LOCAL USER ACCOUNTS	62

M

MANUAL - HOW TO USE	8
MATERIALS - REQUIRED	37
MIGRATE D20MX APPLICATION DEFINITIONS TO SGCONFIG 69	
MODEMS	23

O

OPERATIONAL LEDS	85
OVERVIEW	
cabling	41
D20 chassis	19

D20MX processor	16
product	15

P

PACKAGE CONTENTS	38
PERIODIC INSPECTION	87
PERIPHERALS	23
PHYSICAL SPECIFICATIONS	28
PORT - RS-232	49
POWER SUPPLIES	22
POWER-UP	57
POWER-UP AND TEST REQUIREMENTS	55
POWER-UP AND TEST STEPS	56
PRECAUTIONS	
safety	13
warning symbols	14
PREREQUISITES FOR IMAGE DOWNLOAD	63
PRODUCT	
overview	15
return	12
specifications	27
PRODUCT DESIGN	15

R

RECOMMENDATIONS	
storage	29
storage conditions	29
RECOVERY MODE USER ACCOUNT	62
REDUNDANCY	
LAN	46
system	49
system - test	58
REGULATORY COMPLIANCE	15
CE mark	15
REMOTE USER ACCOUNTS	62
REMOVAL - D20MX	87
REQUIRED	
materials	37
tools	37
REQUIREMENTS - TESTING	55
RETROFIT D20MX	35
RETURN PRODUCT	12
REVERT OLD FIRMWARE	69
RS-232 PORT	49

S

SAFETY PRECAUTIONS	13
SECURITY	16
SERIAL CABLING	43
SGCONFIG	
Migrate D20MX Application Definitions	69
SHELL	56
SOFTWARE	

applications	16	remote	62
download over serial	64		
introduction	61		
licensing	82		
prerequisites	63		
specifications	28		
Tera Term set up	64		
when to download	63		
SPECIFICATIONS			
communications	27		
electric	27		
environment	28		
physical	28		
product	27		
software	28		
system	27		
STANDARDS AND PROTECTION COMPLIANCE	97		
STORAGE			
conditions	29		
recommendations	29		
SUPPORT			
customer	11		
technical	11		
SWITCH-OVER			
check	59		
verify hardware or software	60		
SYSTEM			
redundancy	49		
specifications	27		
T			
TECHNICAL SUPPORT	11		
TERA TERM SET UP	64		
TERMINAL			
emulation	56		
WESMAINT II+	56, 57		
TERMINAL EMULATOR	64		
TEST			
automatic on-line startup	57		
fail-over	59		
requirements	55		
switch-over	59		
system redundancy	58		
TOOLS - REQUIRED	37		
TRANSFER D20/D200 CONFIGURATIONS	70		
TWISTED-PAIR	44		
U			
UNPACKING THE D20MX	38		
UPDATE D20/D200 CONFIGURATIONS	78		
UPGRADE FIRMWARE	12		
UPGRADE KITS	25		
USER ACCOUNTS			
local	62		
recovery	62		

V

VERSIONS

firmware	19
FPGA	19

W

WARNING SYMBOLS	14
WESMAINT II+	56, 57

Modification Record

Version	Revision	Date	Author	Change Description
1.00	0	October 17, 2012	R. Rees	Original release of this document.
	1	November 6, 2012	R. Rees	Updated D20 applications table and added Firmware/FPGA versions table.
	2	November 23, 2012	R. Rees	Added sections for: Update to the SAN0001 firmware option, Transfer D20/D200 configurations to the D20MX, and Updating D20/D200 Configurations to use the D20MX firmware definition with ConfigPro. Added an Appendix for Resetting a read/write user password.
	3	January 11, 2013	R. Rees	Updated procedures for configuring redundant D20MX devices in the Software Configuration chapter.
1.10	0	March 1, 2013	R. Rees	Updated the D20MX applications table. Added Migrate D20MX application definitions to SGConfig section.
1.20	0	July 15, 2013	R. Rees	Updated the D20MX application tables, order code table, upgrade kit order code table, procedures in Chapter 5, and Added Appendix D.

